
INSTALLATION INSTRUCTIONS



Turntite Centris Head Accessory



205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com



KSA1019

KSA1019 Installation Instructions

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



IMPORTANT SAFETY INSTRUCTIONS!

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components does not exceed the weight capacity of the product to which this accessory is attached.

WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.


A

WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.

WARNING: Do not use this product outdoors.

--SAVE THESE INSTRUCTIONS--

DIMENSIONS




Installation Instructions KSA1019

LEGEND


	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
$ \bigodot $	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
41	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
W	Cacciavite a stella	Regolare
(Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
O O	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité

KSA1019 Installation Instructions

TOOLS REQUIRED FOR INSTALLATION



PARTS



Installation Instructions KSA1019

INSTALLATION

WARNING: IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL

DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! DO NOT substitute hardware! Use only hardware provided by manufacturer.

WARNING: EXCEEDING THE WEIGHT CAPACITY CAN RESULT IN SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! It is the installer's responsibility to make sure the combined weight of all components does not exceed the weight capacity of the product to which this accessory is attached.

 Loosen nut at bottom of head assembly and button head cap screw at top to remove head assembly. (See Figure 1)




Figure 1

2. Loosen and remove nut at bottom of KSA-1019 assembly (A) and button head cap screw at top. (See Figure 2)




Figure 2

3. Place new head assembly on arm, tightening the button head cap screw and nut. (See Figure 3)

NOTE: If mounting to height-adjustable arm, the 5/16-18 x 5 1/2" button head cap screw (E) must be used in place of the screw pre-assembled on the assembly.

IMPORTANT!: All pre-assembled washers and spacers must be reassembled when attaching KSA1019 to mounting arm. (See Figure 3)




Figure 3

DISPLAY INSTALLATION

The mounting holes on the back of the display will be *flush with* the back surface, or *recessed into* the back. Refer to the applicable installation procedure below.

NOTE: Ensure Centris Turntite head is able to swivel and tilt easily, yet still be tight enough to hold display in desired position. Adjust as required before proceeding. See **Adjustments** section for details.

Swing Arm Flush Display Installation



CAUTION: IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! Using screws of improper size may damage your display! Proper screws will easily and completely thread into display mounting holes.



CAUTION: IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! Inadequate thread engagement in display may cause display to fall! Back out screws ONLY as necessary to allow installation of Centris Turntite head!

- Using Phillips screwdriver, carefully install two M4 x 12mm Phillips screws (B) into the *upper* mounting holes on the display. Thread screws completely into display, then back out 3 complete turns. (See Figure 4)
- Align two screws (B) (installed on the back of the display in the previous step) with the two top teardrop mounting holes on the Centris cup.



CAUTION: IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! Smaller area of teardrop mounting holes must be facing downward for proper installation. Reposition Centris Turntite head if required.

- 3. Using Phillips screwdriver, install two screws M4 x 12mm Phillips screws (B) through the *lower* mounting holes in Centris Turntite head into the display. (See Figure 4)
- 4. Tighten all four screws (B). Do not overtighten!




Figure 4

Installation Instructions KSA1019

Swing Arm Recessed Display Installation

- Carefully place display face down on a clean and dry surface.
- 2. Determine depth of recessed mounting holes relative to back surface of display.
- 3. Select proper length spacer and screw from table below:

IF recess DEPTH is:	THEN use spacer:	AND screw:
3/8" or less	F (3/8" long)	C (M4 x 20mm)
More than 3/8" up to and including 3/4"	G (3/4" long)	D (M4 x 30mm)

IMPORTANT!: All spacers used should be the same length. If the recess depths result in multiple spacer lengths, then select the longer spacer.

- Place the four (F or G) spacers over each mounting hole on the back of display. (See Figure 5)
- Orient mount so that mounting holes in the Centris Turntite head are aligned with the holes in the spacers (F or G). Rotate the Centris Turntite head as required (See Figure 5).



CAUTION: IMPROPER INSTALLATION CAN LEAD TO DISPLAY FALLING CAUSING SERIOUS PERSONAL INJURY OR DAMAGE TO EQUIPMENT! Using screws of improper size may damage your display! Proper screws will easily and completely thread into display mounting holes.

- 6. Using Phillips screwdriver, install four Phillips screws (C or D) through the mounting holes in Centris Turntite head and the spacers (F or G), into display. (See Figure 5)
- 7. Tighten all four screws. Do not overtighten!
- 8. Return to mount installation section to continue.




Figure 5

Adjustments

The KSA1019 provides for Pitch, Roll, Yaw and display pivot tension adjustment.

To adjust display Pitch/Roll/ Yaw tension:

 Turn adjustment knob, located on back of Centris Turntite head, clockwise to increase tension or counter-clockwise to decrease. (See Figure 6)




Figure 6

To adjust display pivot tension:

 Using hex wrench provided (G), turn adjustment screw clockwise to increase tension or counter-clockwise to decrease tension. (See Figure 7)




Figure 7

KSA1019 Installation Instructions



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies

8800-002122 Rev00 ©2011 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 09/11 **USA/International**

A 8401 Eagle Creek Parkway, Savage, MN 55378

P 800.582.6480 / 952.894.6280

F 877.894.6918 / 952.894.6918

A Fellenoord 130 5611 ZB EINDHOVEN, The Netherlands

P +31 (0)40 2668620

F +31 (0)40 2668615

Asia Pacific

Europe

Office No. 1 on 12/F, Shatin Galleria

18-24 Shan Mei Street Fotan, Shatin, Hong Kong

P 852 2145 4099 **F** 852 2145 4477

