


INSTRUCTION MANUAL FOR DL-5040



REMARK :

- 1 INSTALLATION SHOULD BE CARRIED OUT BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH APPROPRIATE NATIONAL WIRING REGULATION.
- 2 DISCONNECT THE POWER BEFORE CHANGING THE LAMP.
- 3 THIS IS CLASS 1 LIGHTING FIXTURE AND MUST BE EARTHED.
- 4 DO NOT EXCEED THE MAXIMUM WATTAGE.

Applicable lamp :

1	230V 50Hz MAX HME 80W
2	230V 50Hz MAX HSE 70W
3	230V 50Hz MAX HIE 70W
4	230V 50Hz MAX TC-TEL 42W

