


Product Data Sheet
Edition 4.13.2009
Identification no. 431
Sikaflex-1a

Sikaflex®-1a

One part polyurethane,
elastomeric sealant/adhesive

 SEALANT · WATERPROOFING & RESTORATION INSTITUTE	
Issued to: Sika Corporation Product: Sikaflex 1A Construction Sealant	
C719: Pass	Ext:+35% Comp:-35%
Substrate: Mortar, Aluminum, Glass <small>[mortar substrate primed with Sikaflex 429 Primer]</small>	
C661: Rating 40	
Validation Date: 12/22/06 - 12/21/11	
No. 1206-S1A11 <small>Copyright © 2006</small>	
SEALANT VALIDATION www.swrionline.org	

Description	Sikaflex-1a is a premium-grade, high-performance, moisture-cured, 1-component, polyurethane-based, non-sag elastomeric sealant. Meets Federal specification TT-S-00230C, Type II, Class A. Meets ASTM C-920, Type S, Grade NS, Class 35, use T, NT, O, M, G, I; Canadian standard CAN/CGSB 19.13-M87.
Where to Use	<ul style="list-style-type: none"> ■ Designed for all types of joints where maximum depth of sealant will not exceed 1/2 in. ■ Excellent for small joints and fillets, windows, door frames, reglets, flashing, common roofing detail applications, and many construction adhesive applications. ■ Suitable for vertical and horizontal joints; readily placeable at 40°F. ■ Has many applications as an elastic adhesive between materials with dissimilar coefficients of expansion. ■ Submerged conditions, such as canal and reservoir joints.
Advantages	<ul style="list-style-type: none"> ■ Eliminates time, effort, and equipment for mixing, filling cartridges, pre-heating or thawing, and cleaning of equipment. ■ Fast tack-free and final cure times. ■ High elasticity - cures to a tough, durable, flexible consistency with exceptional cut and tear-resistance. ■ Stress relaxation. ■ Excellent adhesion - bonds to most construction materials without a primer. ■ Excellent resistance to aging, weathering. ■ Proven in tough climates around the world. ■ NSF Registered, meets 1998 USDA guidelines. ■ Odorless, non-staining. ■ Jet fuel resistant. ■ NSF Certified to NSF/ANSI Standard 61 for potable water contact. ■ Urethane-based; suggested by EPA for radon reduction. ■ Paintable with water-, oil- and rubber-based paints. ■ Capable of ±35% joint movement.
Coverage	10.1 fl. oz. cartridge seals 12.4 lineal ft. of 1/2 x 1/4 in. joint. 20 fl. oz. uni-pac sausage seals 24 lineal ft. of 1/2 x 1/4 in. joint.
Packaging	Disposable 10.1 fl. oz., moisture-proof composite cartridges, 24/case; and uni-pac sausages, 20 fl. oz., 20/carton.

Typical Data (Material and curing conditions @ 73°F (23°C) and 50% R.H.)

Shelf Life	10.1 fl. oz. cartridges	12 months
	20 fl. oz. uni-pac sausages	12 months
	5 gallon pail	6 months
	55 gallon drum	6 months
Storage Conditions	Store at 40°-95°F (4°-35°C). Condition material to 65°-75°F before using.	
Colors	White, colonial white, aluminum gray, limestone, black, dark bronze, capitol tan. Special architectural colors on request.	
Application Temperature	40° to 100°F. Sealant should be installed when joint is at mid-range of its anticipated movement.	
Service Range	-40° to 170°F	
Curing Rate	Tack-free time	4 hours
	Tack-free to touch	3 hours
	Final cure	4 to 7 days
Tear Strength (ASTM D-624)	55 lb./in.	
Shore A Hardness (ASTM D-2240)	21 day	40±5
Tensile Properties (ASTM D-412)	21 day	
	Tensile Stress	175 psi (1.21 MPa)
	Elongation at Break	550%
	Modulus of Elasticity	25% 35 psi (0.24 MPa)
		50% 60 psi (0.41 MPa)
		100% 85 psi (0.59 MPa)
Adhesion in Peel (TT-S-00230C, ASTM C 794)		
	Substrate	Peel Strength Adhesion Loss
	Concrete	20 lb. 0%
	Aluminum	20 lb. 0%
	Glass	20 lb. 0%

Weathering Resistance Excellent

Chemical Resistance Good resistance to water, diluted acids, and diluted alkalines. Consult Technical Service for specific data.



How to Use

Surface Preparation

Clean all surfaces. Joint walls must be sound, clean, dry, frost-free, and free of oil and grease. Curing compound residues and any other foreign matter must be thoroughly removed. Install bond breaker tape or backer rod to prevent bond at base of joint.

Priming

Priming is not usually necessary. Most substrates only require priming if testing indicates a need or where sealant will be subjected to water immersion after cure. Consult Sikaflex Primer Technical Data Sheet or Technical Service for additional information on priming.

Application

Recommended application temperatures: 40°-100°F. For cold weather application, condition units at approximately 70°F; remove prior to using. For best performance, Sikaflex-1a should be gunned into joint when joint slot is at mid-point of its designed expansion and contraction. Place nozzle of gun into bottom of the joint and fill entire joint. Keep the nozzle in the sealant, continue on with a steady flow of sealant preceding the nozzle to avoid air entrapment. Avoid overlapping of sealant to eliminate entrapment of air. Tool sealant to ensure full contact with joint walls and remove air entrapment. Joint dimension should allow for 1/4 inch minimum and 1/2 inch maximum thickness for sealant. Proper design is 2:1 width to depth ratio, For use in horizontal joints in traffic areas, the absolute minimum depth of the sealant is 1/2 in. and closed cell backer rod is recommended.

Limitations

- Allow 1-week cure at standard conditions when using Sikaflex-1a in total water immersion situations and prior to painting.
- When overcoating with water, oil and rubber based paints, compatibility and adhesion testing is essential.
- Avoid exposure to high levels of chlorine. (Maximum continuous level is 5 ppm of chlorine.)
- Maximum depth of sealant must not exceed 1/2 in.; minimum depth is 1/4 in.
- Maximum expansion and contraction should not exceed 25% of average joint width.
- Do not cure in the presence of curing silicone sealants.
- Avoid contact with alcohol and other solvent cleaners during cure.
- Do not apply when moisture-vapor-transmission condition exists from the substrate as this can cause bubbling within the sealant.
- Use opened cartridges and uni-pac sausages the same day.
- When applying sealant, avoid air-entrapment.
- Since system is moisture-cured, permit sufficient exposure to air.
- White color tends to yellow slightly when exposed to ultraviolet rays.
- Light colors can yellow if exposed to direct gas fired heating element.
- The ultimate performance of Sikaflex-1a depends on good joint design and proper application with joint surfaces properly prepared.
- The depth of sealant in horizontal joints subject to traffic is 1/2 in.
- Do not tool with detergent or soap solutions.
- Do not use in contact with bituminous/asphaltic materials.

Caution

Irritant

Keep away from open flames and high heat. Contains xylene; avoid breathing vapors. Use with adequate ventilation.

Combustible

Avoid skin and eye contact. Use of NIOSH approved organic vapor respirator, safe and chemical-resistant gloves recommended. Remove contaminated clothing and shoes.

First Aid

In case of skin contact, wash thoroughly with soap and water. For eye contact, flush immediately with plenty of water for at least 15 minutes; contact physician. Wash clothing before re-use. Discard contaminated shoes.

Clean Up

Uncured material can be removed with approved solvent. Cured material can only be removed mechanically. For spillage, collect, absorb, and dispose of in accordance with current, applicable local, state, and federal regulations.

Linear Feet of Sealant per Gallon

Inches	Depth					
	1/4	1/2	3/4	1	1 1/4	1 1/2
1/4	308.0					
1/2	154.0	77.0				
3/4	102.7	51.3	34.2			
1	77.0	38.5	25.7	19.3		
1 1/4	61.6	30.8	20.5	15.4	12.3	
1 1/2	51.3	25.7	17.1	12.8	10.3	8.6

Width

KEEP CONTAINER TIGHTLY CLOSED • KEEP OUT OF REACH OF CHILDREN • NOT FOR INTERNAL CONSUMPTION • FOR INDUSTRIAL USE ONLY
 All information provided by Sika Corporation ("Sika") concerning Sika products, including but not limited to, any recommendations and advice relating to the application and use of Sika products, is given in good faith based on Sika's current experience and knowledge of its products when properly stored, handled and applied under normal conditions in accordance with Sika's instructions. In practice, the differences in materials, substrates, storage and handling conditions, actual site conditions and other factors outside of Sika's control are such that Sika assumes no liability for the provision of such information, advice, recommendations or instructions related to its products, nor shall any legal relationship be created by or arise from the provision of such information, advice, recommendations or instructions related to its products. The user of the Sika product(s) must test the product(s) for suitability for the intended application and purpose before proceeding with the full application of the product(s). Sika reserves the right to change the properties of its products without notice. All sales of Sika product(s) are subject to its current terms and conditions of sale which are available at www.sikacorp.com or by calling 800-933-7452.

Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's most current Technical Data Sheet, product label and Material Safety Data Sheet which are available online at www.sikaconstruction.com or by calling Sika's Technical Service Department at 800-933-7452. Nothing contained in any Sika materials relieves the user of the obligation to read and follow the warnings and instruction for each Sika product as set forth in the current Technical Data Sheet, product label and Material Safety Data Sheet prior to product use.

LIMITED WARRANTY: Sika warrants this product for one year from date of installation to be free from manufacturing defects and to meet the technical properties on the current Technical Data Sheet if used as directed within shelf life. User determines suitability of product for intended use and assumes all risks. Buyer's sole remedy shall be limited to the purchase price or replacement of product exclusive of labor or cost of labor. **NO OTHER WARRANTIES EXPRESS OR IMPLIED SHALL APPLY INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SIKASHALL NOT BELIEVABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES. SIKASHALL NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS.**

Visit our website at www.sikaconstruction.com

1-800-933-SIKA NATIONWIDE

Regional Information and Sales Centers. For the location of your nearest Sika sales office, contact your regional center.

Sika Corporation
 201 Polito Avenue
 Lyndhurst, NJ 07071
 Phone: 800-933-7452
 Fax: 201-933-6225

Sika Canada Inc.
 601 Delmar Avenue
 Pointe Claire
 Quebec H9R 4A9
 Phone: 514-697-2610
 Fax: 514-694-2792

Sika Mexicana S.A. de C.V.
 Carretera Libre Celaya Km. 8.5
 Fracc. Industrial Balvanera
 Corregidora, Queretaro
 C.P. 76920
 Phone: 52 442 2385800
 Fax: 52 442 2250537



Sika and Sikaflex are registered trademarks. Made in USA. Printed in Canada.

