



FLEXIBLE KNEE PAD

FEATURES

- Flexible, lightweight and comfortable foam padding.
- Water resistant cap.
- Debris guard to prevent debris from entering.
- Size adjustable straps for a custom fit.
- Buckles to quickly put on and off the knee pad.
- European Certified knee protectors: EN 14404 performance level 1.

MODELS

DESCRIPTION	MATERIAL	NO. OF PAIRS	PACK QUANTITY	STANDARD AND RATING	ARTICLE NUMBER
FLEXIBLE KNEE PAD - 1 PAIR	SHELL: PVC; FOAM: EVA	1	1	EN 14404:2004+A1:2010 (PERFORMANCE LEVEL 1)	4932478136



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany





FLEXIBLE KNEE PAD

CARE INSTRUCTIONS

No wash;No bleach;No tumbler;No iron;No dry clean

STORAGE INSTRUCTIONS

Store in a cool and dry place, protected from frost and sunlight. Do not place heavy loads on the knee protectors.

USAGE INSTRUCTIONS

The padded side faces the body. Pay attention to the left and right. The assignment can be seen on the label or on the knee protectors. L = left, R = right Fasten the knee protectors to the thigh and lower leg with straps so that the knee area is covered. The upper edge of the knee protectors should protrude 2 cm from the bent knee. Fasten the straps parallel, not crosswise. Make sure that the velcro straps are not too tight. Do not let the velcro straps go over the back of the knee. This could impair the blood supply.



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany





HARD KNEE PAD

FEATURES

- Thick comfortable foam padding with a supporting gel zone.
- Durable hard cap which withstands rough surfaces.
- Size adjustable double straps for a better hold and a custom fit.
- Buckles with metal rivets that withstand repeated fastenings.
- 1680D Ballistic Nylon for a long lifetime.
- European Certified knee protectors: EN 14404 performance level 2.

MODELS

DESCRIPTION	MATERIAL	NO. OF PAIRS	PACK QUANTITY	STANDARD AND RATING	ARTICLE NUMBER
HARD KNEE PAD - 1 PAIR	CAP: PE; SHELL: POLYESTER; FOAM: EVA + PU; GEL: GEL	1	1	EN 14404:2004+A1:2010 (PERFORMANCE LEVEL 2)	4932478137



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany





HARD KNEE PAD

CARE INSTRUCTIONS

No wash;No tumbler;No iron;No dry clean

STORAGE INSTRUCTIONS

Store in a cool and dry place, protected from frost and sunlight. Do not place heavy loads on the knee protectors.

USAGE INSTRUCTIONS

The padded side faces the body. Pay attention to the left and right. The assignment can be seen on the label or on the knee protectors. L = left, R = right Fasten the knee protectors to the thigh and lower leg with straps so that the knee area is covered. The upper edge of the knee protectors should protrude 2 cm from the bent knee. Fasten the straps parallel, not crosswise. Make sure that the velcro straps are not too tight. Do not let the velcro straps go over the back of the knee. This could impair the blood supply.



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany





PREMIUM NON-MARKING KNEE PAD

FEATURES

- High density foam padding with a supporting premium gel injection.
- Non-marking coating to prevent scratches on sensitive surfaces.
- Comfortable and size adjustable double straps with a wider lower strap.
- Buckles with metal rivets that withstand repeated fastenings.
- 1680D Ballistic Nylon for a long lifetime.
- European Certified knee protectors: EN 14404 performance level 1.

MODELS

DESCRIPTION	MATERIAL	NO. OF PAIRS	PACK QUANTITY	STANDARD AND RATING	ARTICLE NUMBER
PREMIUM NON- MARKING KNEE PAD - 1 PAIR	CAP: TPR; SHELL: POLYESTER; FOAM: PU; GEL: GEL	1	1	EN 14404:2004+A1:2010 (PERFORMANCE LEVEL 1)	4932478139



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany





PREMIUM NON-MARKING KNEE PAD

CARE INSTRUCTIONS

No wash;No bleach;No tumbler;No dry clean

STORAGE INSTRUCTIONS

Store in a cool and dry place, protected from frost and sunlight. Do not place heavy loads on the knee protectors.

USAGE INSTRUCTIONS

The padded side faces the body. Pay attention to the left and right. The assignment can be seen on the label or on the knee protectors. L = left, R = right Fasten the knee protectors to the thigh and lower leg with straps so that the knee area is covered. The upper edge of the knee protectors should protrude 2 cm from the bent knee. Fasten the straps parallel, not crosswise. Make sure that the velcro straps are not too tight. Do not let the velcro straps go over the back of the knee. This could impair the blood supply.



Disclaimer Information present within this sheet was correct at the date of issue. Techtronic Industries GmbH 71364 Winnenden Germany