



uponor

RADIANT HEATING AND
COOLING SYSTEMS

THERMAL ZONE VALVES

TECHNICAL BULLETIN

Thermal Zone Valve Stem Assembly Improper Stroke Dimension

Affected Product

$\frac{3}{4}$ " Thermal Zone Valve, four wire
(A3010525)

1" Thermal Zone Valve, four wire
(A3010526)

Symptom

Rooms or spaces overheat.

Issue

Original zone valves had incorrect valve stem assemblies that do not meet our dimension-travel requirements.

Corrective Action

Order the following valve stem assemblies (at no charge) through your regular ordering process.

A2450029 for $\frac{3}{4}$ " valve bodies
A2450030 for 1" valve bodies

Note: Do not use part number A2450028, as they are manifold replacements and will not work in the valves. As an alternative, you can use Uponor's Motorized Valve Actuator (A3020522) as a replacement to correct this issue.

Uponor, Inc.
5925 148th Street West
Apple Valley, MN 55124 USA
Tel: 800.321.4739
Fax: 952.891.2008
Web: www.uponor-usa.com

Uponor Ltd.
2000 Argentia Rd., Plaza 1, Ste. 200
Mississauga, ON L5N 1W1 CANADA
Tel: 888.994.7726
Fax: 800.638.9517
Web: www.uponor.ca