

PERFECT Lite Hybrid/ Lite Hybrid Advanced

The PERFECT Lite Hybrid with the additional free-float functionality activates muscles in the lower back and abdomen. Specially designed depressions minimise discomfort.

Description

Seat height	49-89 cm
Seat dimensions	32x39 cm
Gas spring options	3
Alternative castors	Yes
Base diameter	50 cm
Adjustable seat	Free-float
Upholstery	Scandinavian leather, vinyl or fabric
Weight	9 kg
Max. load	120 kg
Warranty	5 years

Accessories

Foot ring	Foot rest while working in high chair positions
SWING arm rest	Arm rest that doubles as a back and abdominal support. Can swivel 360° for complete freedom and versatility



Seat Heights

User height	Gas spring	Seat height	Seat height with SWING
< 160 cm	Short	49-63 cm	57-65 cm
160-175 cm	Standard	56-75 cm (standard)	64-77 cm
> 175 cm	High	63-89 cm	72-91 cm

Key Features

Mechanism

Patented free-float feature is lockable in the basic position with adjustable height and up to 15° lateral movement.

Seat

Unisex mould with recyclable polymer frame.

Padding

Upholstered with injection moulded polyurethane foam, recyclable when using a certain process.

Upholstery

Our standard vinyl contains 100% polyurethane with cotton and polyester backing. It is PVC and Phthalate free. It is also OEKO-TEX certified, which means that the upholstery is easy to clean, and resistant to disinfectants and common cleaning product.

Gas spring

Columns are available in three sizes. The spring is made of polished steel in Germany using nitrogen, a sustainable gas existing in 78% of normal air. Gas springs are maintenance-free and recyclable.

Base

Polished recyclable aluminium.

Castors

Cores are made from polyamide 6 and tread is made of recyclable polyurethane. (Note: larger castor base is required when using SWING support arm).