Eva Technical Specification

Grab Bar

YG2812/YG2818/YG2824

Stock Numbers:

- YG2812CH 12" Grab Bar Chrome Finish
- YG2818CH 18" Grab Bar Chrome Finish
- YG2824CH 24" Grab Bar Chrome Finish
- YG2812BN 12" Grab Bar **Brushed Nickel Finish**
- YG2818BN 18" Grab Bar **Brushed Nickel Finish**
- YG2824BN 24" Grab Bar П **Brushed Nickel Finish**
- YG2812ORB 12" Grab Bar Oil Rubbed Bronze Finish
- YG2818ORB - 18" Grab Bar Oil Rubbed Bronze Finish
- YG2824ORB 24" Grab Bar Oil Rubbed Bronze Finish

Materials:

Grab Bar posts and bars are constructed of stainless steel.

Compliance:

- ADA, ANSI, ASTM, CSA
- Tested to 500lbs. pull



Dimensions:



Installation Instructions:

- Please note that screws MUST be mounted into a wood stud for secure installation 2.
 - Slide the decorative cover away from the hub end to expose the SecureMount™ mounting flange. Do not remove protective plastic from decorative cover until indicated later in these instructions.
- 3. Locate the studs behind the wall by using a stud sensor or other stud locating method. Studs are usually 16 in. apart; locate the center of each stud.
- Moving aside the decorative cover as needed, with a pencil, mark three of the mounting locations on each of the two 4. grab bar flanges. Two marks to be made above the grab bar. The third mark to be made below the grab bar. Decide whether you would like to position your grab bar horizontally, vertically or at an angle, remembering that BOTH ends of the grab bar MUST be positioned over a wood stud.
- 5. Moving the decorative cover as far away from the marked slots as possible, drill a hole into the marks, through the slots. Position the drill at a slight angle in order to get around the grab bar and decorative cover, making sure to drill into the wood stud. If desired, apply silicone caulk to the back of the decorative cover to guard against water penetration. To mount the grab bar, reposition one end of the grab bar SecureMount™ mounting flange over the marked holes 6.
- 7. Thread a washer onto each screw. Using the screwdriver, screw the wood screws with washers into the SecureMount™ mounting flange at one end of the grab bar. Then screw the wood screws with washers into the mounting flange at the other end of the grab bar.
- Tighten the screws until secure 8
- Slide the decorative cover over the SecureMount™ mounting flange, rotating to find the correct fit before snapping into place. 10. Slide decorative covers over SecureMount™ mounting flanges

Cleaning Instructions:

To preserve the fine finish of this product, clean only with a soft damp cloth. Dry well. Do not use commercial or abrasive cleaners.

Stock Number: By Moen Incorporated Grab Bar

25300 AL MOEN DRIVE • NORTH OLMSTED, OH 44070 CORPORATE HEADQUARTERS: (800) 321-8809 • FAX: (800) 848-6636 INTERNATIONAL: (440) 962-2000 • FAX: (440) 962-2726 CUSTOMER SERVICE (USA): 800-882-0116 • FAX: (888) 379-2720 WWW.MOEN.COM © 2015 Moen Incorporated. Moen is a registered trademark and Eva is a trademark of

Moen Incorporated. All rights reserved.