

**HYG** 



# **GETTING STARTED:**



**CLEAN** the laundry machines daily, before the first use.

3.

**WASH** Rubbermaid HYGEN Microfiber Cloths and Mops in the Rubbermaid Mesh Laundry Net to manage inventory.



**SEPARATE** Rubbermaid HYGEN<sup>™</sup> Microfiber Cloths and Mops from other textiles.

4.

**DETERMINE** detergent and maximum load size using chart below.\*

# **DETERGENT AND LOAD SIZE BY MACHINE**

Washer Size	Max Volume	Detergent Load**	18"/45cm mops per load
60 lb. / 27.2 kg	71.8 gal. / 272L	1.5 oz. / 44.4ml	130
81.6 lb. / 37 kg	97.8 gal. / 370L	2.0 oz. / 59.2ml	175
101.4 lb. / 46 kg	121.3 gal. / 1014L	2.5 oz. / 73.9ml	220
125 lb. / 56.7 kg	150.6 gal. / 570L	3.1 oz. / 91.7ml	270
141.4 lb. / 64.3 kg	169.6 gal. / 642L	3.5 oz. / 103.5ml	305
174.8 lb. / 79.3 kg	201 gal. / 761L	4.2 oz. / 124.2ml	375

# LAUNDRY INSTRUCTIONS



**COMMERCIAL WASHING: HOT WATER METHOD** 



**COMMERCIAL DRYING** Dry cloths and mops on low heat

- $\Box$  Wash in hot water (160°F/71°C) for 25 minutes<sup>1</sup>
- □ Use Detergent and Load Size By Machine Guide to select appropriate capacity setting
- □ Use bleach if necessary



#### **COMMERCIAL WASHING: COLD WATER METHOD**

- □ Wash in cold water
- □ Use Detergent and Load Size By Machine Guide to select appropriate capacity setting
- □ Bleach is required at 50-150ppm<sup>2</sup>

# TRANSPORTATION

	A		
П	77777		
	Ш <u>"</u>		

### **CONTAMINATED TEXTILES**

- Don Personal Protective Equipment (PPE) before transferring soiled textiles into laundry machine
- □ Handle contaminated textiles carefully to avoid agitation
- □ Sort soiled Rubbermaid HYGEN Microfiber Cloths and Mops from other textiles at the point of contamination using the Rubbermaid Mesh Laundry Net



Transport soiled textiles to the laundry with black Rubbermaid Cube Truck with Cover

## (130°F/54°C) setting

□ Store dry cloths and mops in clean Rubbermaid Cube Truck

### **REQUIRED CARE**

- Do not store Rubbermaid HYGEN Cloths or Mops in a washing machine overnight
- Do not use fabric softener in the wash cycle
- Do not use dryer sheets in the dry cycle
- Do not wash Rubbermaid HYGEN Cloths or Mops with other textiles



#### **CLEAN TEXTILES**

- □ Remove dry textiles from the dryer immediately
- □ Transport clean textiles in a properly cleaned blue Rubbermaid Cube Truck with Cover or Rubbermaid X-Cart with Cover



OR

- Store clean textiles for only short periods of time. Wrap clean textiles for long-term storage
- Distribute textiles back into facility

Always follow the protocol as directed by your facility manager. <sup>1</sup>Per CDC Guidelines for healthcare facilities. <sup>2</sup>Follow manufacturer instructions for bleach use.

<sup>\*</sup>Machine settings can be established by chemical provider. \*\*Represents 1/2 the average manufacturer's detergent recommendation. Using full amount of detergent can result in hazy floors.