Cleaning Instructions

SuperScrape mats can be cleaned in several different ways.

- Commercially laundered (see Laundering Instructions)
- Sterilized in an autoclave
- Washed by hand using the following instructions: Scrub with a deck brush (as needed), using a detergent with a neutral pH. Rinse with a hose or pressure washer. Hang to dry.

Laundering Instructions

SuperScrape mats can be commercially laundered periodically to remove soil. The formula below does not require extensive mechanical action or drying.

- 1. Flush 2-3 minutes, high water level, cold
- 2. Break 5-10 minutes, high water level, 120 degrees F (49 degrees C)
- 3. Rinse 2 minutes, high water level, cold
- 4. Rinse 2 minutes, high water level, cold
- 5. Drain 2 minutes
- 6. Rotate wash well with drain valve in open position to allow excess water to drain off mats.
- 7. Lay mats flat following removal from washer. Allow to cool before rolling.