


#89788 Study Carrel

Adjustable Height Workcenter



Assembly Instructions

Study Carrel

Adjustable Height Workcenter

Part Drawing	Description	Qty	Part	Drawing	g Description	Qty
P1	Right Side Panel	1 EA	P8		Stability Brace	1 EA
P2 ::	Left Side Panel	1 EA	P9		Metal Angle Bracket	8 EA
P3	Top Platform	1 EA			Hardware List	
	•		A	Θ	½" Socket Screw	4 EA
P4	Upper Shelf Platform	n 1EA	A1		1-1/2" Socket Screw	8 EA
P5		1 EA	В		Threaded Nut	4 EA
	Back Panel		С		Wood Screw	24 EA
P6	ð	2 EA	D		Plastic Grommet	2 EA
	Upper Leg Reciever		E		Leveling Glide	4 EA
P7		2 EA	F		Allen Wrench	1 EA
	Lower Leg Insert		G		Cam Lock	16 EA
)		Н		Cam Post	16 EA
We recommend that you assemble this unit on a table.						
	ljustable Crescent Wren					

Missing Parts or UPS Damaged Parts

For Your Convenience you can EMAIL us at


furniture@baltinc.com 24HOURS 7 DAYS A WEEK Should you require assistance during assembly, please call our Customer Service Department Monday - Friday 8 a.m. - 5 p.m.

Central Standard Time 1-800-749-2258


Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.

Study Carrel Assembly Diagram






2.) Place the Upper Shelf Platform (P4) with the Holes facing up and install 6 each Cam Locks (G) into the large holes as shown in illustration # 1.



- 5.) Place the Left Side Panel (P2) with the insert nuts facing up.
- 6.) Install 6 each Cam Posts (H) in the 6 threaded insert nuts (Pre-installed) as shown in illustration #3.


7.) Repeat Steps 5 & 6 for the Right Side Panel(P6).




8.) Place the Top Platform (P3) with the Holes facing up and install 6 each Cam Locks (G) into the large holes as shown in illustration #4.




- 9.) Place the Back Panel (P5) with the insert nuts facing up. Slide 1 each Upper Shelf Platform (P4) over the Cam Posts (H) as shown in illustration # 5. Secure by turning the Cam Locks (H) 1/4 Turn until they lock.
- 10.) Slide 1 each Top Platform (P3) over the Cam Posts (H) as shown in illustration #5 and secure by turning the Cam Locks (H) 1/4 Turn until they lock. (Finger tighten only)





To Secure Cam Locks, Insert Large Phillips Head Screwdriver and turn Cam Lock 1/4 turn (90 degrees) clockwise. Illustration # 5






14) Rotate the Carrel Assembly so that the Bottom Platform (P-3) is facing up. Attach 2 each Upper Receivers (P6) to the Bottom Platform (P-3) using 4 each (A1) screws as shown in illustration #9.


(Finger tighten only)

15.)Attach Stability Brace(P8) to the 2 each Upper Receivers (P6) using 4 Screws (A1) and 4 Threaded Nuts (B) as shown in illustration #6.



(A1) Screw M6 X 1-1/2" For Scale only






16.) Slide 2 Lower Leg Inserts (P7) into the Upper Leg Receivers (P6). Secure at desired height using (4) each (A) Screws as shown in illustration #10.

(Tighten all the screws at this time using Allen Wrench (F)).

17.) Attach 4 each (E) Leveling Glides to the 2 each Lower Leg Inserts (P7).




(C) Screw M6 X 9/16" For Scale only


Illustration #10

Grommet(D) installation Illustration #11

18.) To install Grommet (D), separate parts and press Grommet Sleeve in Round openings in Bottom Platform (P3) and Back Panel (P4) as shown in illustration #8.

19.) Snap plastic Caps into Sleeves as shown in illustration #11.





The Balt product you have purchased is guaranteed against material and workmanship defects. This guarantee extends 1 year from date of purchase. Should this product fail to function satisfactorily under normal use due to defect or imperfection, the defective part or product will be replaced. Damage caused by common carriers during shipment is not included in this guarantee.

This guarantee sets forth all applicable guarantees and remedies. No other warranty, expressed or implied shall apply. Failure to follow instructions found in Important Information Section of Owner Sheet shall void the guarantee. Consequential or incidental damages and or costs are not refundable.

89788-Study Carrel Workcenter



