

# Supplement

Title:	59 MAX/59 MAX +Users	Supplement Issue:	1
Part Number:	4311999	Issue Date:	10/13
Print Date:	March 2005	Page Count:	1
Revision/Date:			

---

---

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.



## Change #1

On page 18 add:

To verify operation of the Product:

1. With a calibrated contact thermometer that you know to be good, measure the temperature of a surface that has a known temperature and emissivity.
2. Take the same measurement with the 59 Max and compare the result to that of the contact thermometer in step 1.

A calibrated “black body” temperature standard with a temperature display may also be used.