

# Manual Supplement

Manual Title: TiS Users  
Print Date: June 2010  
Revision/Date:

Supplement Issue: 1  
Issue Date: 10/10  
Page Count: 1

---

---

This supplement contains information necessary to ensure the accuracy of the above manual. This manual is distributed as an electronic manual on the following CD-ROM:

CD Title:	TiS
CD Rev. & Date:	6/2010
CD PN:	3803345

## Change #1,

On page 11, following **Making Accurate Temperature Measurements** add:

### *Note*

*All thermal imagers require appropriate warm-up time in order to obtain the most accurate temperature measurement. This time can often vary by model and by environmental conditions. Although most imagers are fully warmed-up within 3-5 minutes, it is always a best practice to wait at least 10 minutes if the most accurate temperature measurement is critical to your application. Whenever changing or adding optional lenses, additional stabilization time may be required depending on the situation.*



205 Westwood Ave  
Long Branch, NJ 07740  
1-877-742-TEST (8378)  
Fax: (732) 222-7088  
salesteam@Tequipment.NET