



# GeigerLink™

## Connect Your Geiger Counter to the World

Works with the IMI Gateway App

Mac OSX - Windows 10

Designed to be an essential asset for:

- Research
- Radiation Safety Professionals
- Community Monitoring Projects
- Science, Learning, Citizen Science

With GeigerLink you can:

- Continuously monitor and record ambient radiation levels on your computer
- Observe changes in radiation levels in your environment over time
- Share your data. Works with RadResponder and Safecast Networks.
- Get creative and customize your radiation monitoring project.

Getting Started is Easy:

- Install the IMI Gateway App
- Connect the provided 3.5 mm cable to your Medcom Geiger Counter
- Connect GeigerLink to your computer using the provided USB cable.
- Start the IMI Gateway App and configure your instrument.



Our GeigerLink Kit includes:

1. GeigerLink module
2. USB A to USB B cable (USB C adapter on request)
3. 3.5 mm cable
4. USB data stick with OS X and WIN10 apps

Support is available at [customer care@medcom.com](mailto:customer care@medcom.com) or 877 378-1010 (US Toll Free). See our other IMI products and services at [medcom.com](http://medcom.com)