
peerless-AW®

DS-C555-4X3








This page intentionally left blank.


▲ WARNING


ENG - Do not begin to install product until you have read and understood the instructions and warnings contained in this user guide. Always use an assistant or mechanical lifting equipment to safely lift and position equipment. This product must be installed onto flat, hard, level surface to prevent tipping. Use with heavier displays may result in instability causing tip over resulting in death or serious injury. The cart or stand is not affixed or secured to the floor, and may therefore tip over and/or fall if screen and/or stand is shaken or hit. This product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury. Screws must be tightly secured. Do not overtighten screws or damage can occur and product may fail. Never exceed the Maximum Load Capacity. Be careful not to pinch fingers when operating the mount. Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child. Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child. For support please call customer care at 1-800-865-2112.




Parts (Before beginning, make sure you have all parts shown below).


A C B C C C D b E h F b G b	Description aster, 5" swivel aster support over ase leg orizontal leg support ases support tube ase support	Qty 6 6 9 3 2 3	Part # 600-0026 145-T1799 145-T1809 145-T1767 145-T1785 145-T1812
B C C C D b E h G b	aster support over lase leg lorizontal leg support lase support tube	6 9 3 2	145-T1799 145-T1809 145-T1767 145-T1785
C c D b E h F b G b	over lase leg lorizontal leg support lase support tube	9 3 2	145-T1809 145-T1767 145-T1785
D bE hF bG b	ase leg orizontal leg support ase support tube	3 2	145-T1767 145-T1785
E h F b G b	orizontal leg support ase support tube	2	145-T1785
F b	ase support tube	=	
G b	• • • • • • • • • • • • • • • • • • • •	3	1/5 T1012
	ase support		140-11012
		14	560-T1261
H v	ertical leg support	3	146-T1131
I e	xtension	3	145-T1778
J s	ide support bracket	4	145-T1807
K le	eft adaptor bracket	12	146-1609
L ri	ght adaptor bracket	12	146-1608
M v	ertical support bracket	6	145-T1806
N d	ual cross support	6	146-T1905
O c	omputer cover	1	145-T1930
P c	omputer shelf	1	145-T1931
Q e	xtension adaptor	3	145-T1935
R c	ord bracket	6	146-T1321
S b	racket, 4x2 configuration	3	145-T1858
T k	nob	6	560-1160
U N	//8 x 16mm socket button screw	244	520-9527
V N	18 square nut	80	530-1066
W c	over clip	36	590-0317
ΧN	15 x 10mm type-F, socket pin screw	26	520-1164
	ar nut	34	146-1319
Z 1	/4" power bit	1	560-0263
AA 5	mm allen wrench	1	560-9640
BB n	ylon shoulder washer	48	590-2233
CC N	16 x 12mm socket pin screw	48	520-1050
DD 4	mm allen wrench	1	560-9646


































Ģ

Use metric formula below and diagram to the right to determine hole pattern required for center vertical support bracket. Repeat (x2).


All dimensions are metric.






Use the outside mounting holes when... $% \label{eq:continuous} % \label{eq:c$


a x 4 > 4368mm and a x 3 + b < 4318mm








Use the inside mounting holes when...


 $a \times 4 > 4098mm$ and $a \times 3 + b < 4064mm$


































OPTIONAL: Insert M5 x 10mm type-F socket pin screws (X) to lock latches.










Display Adjustment













17-1




17-2








Route cables through cord brackets.





Display Removal



















Peerless Industries, Inc. ("Peerless-AV") warrants to original end-users that each Peerless-AV® mounting product will be free from defects in material and workmanship, under normal use, for the applicable warranty period (from date of the original installation of the product). At its option, Peerless-AV will repair or replace, or refund the purchase price of, any product which fails to conform with this warranty.

Any implied warranty of merchantability or fitness for a particular purpose shall be limited to the period of the express warranty set forth below.

In no event shall Peerless-AV be liable for incidental or consequential damages, whether or not secured by a security device which may be included with the product.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitation and/or the above exclusion may not apply to you.

This warranty does not cover damage caused by incorrect selection, installation or the failure to follow Peerless-AV instructions or warnings when installing, using or storing the product.

This warranty gives specific legal rights, and you may also have other rights which vary from state to state. To make a warranty claim in North America, contact Peerless-AV customer care at 1-800-865-2112. See complete global warranty information for regions outside North America at www.peerless-av.com/en-uk/customer-care/warranties-returns.



Peerless-AV 2300 White Oak Circle Aurora, IL 60502 Email: tech@peerlessmounts.com Ph: (800) 865-2112 Fax: (800) 359-6500

www.peerless-av.com

Peerless-AV Europe Unit 3 Watford Interchange, Colonial Way, Watford, Herts, WD24 4WP, United Kingdom Customer Care 44 (0) 1923 200 100 www.peerless-av.com

© 2018 Peerless Industries Inc.

Peerless-AV de Mexico Ave de las Industrias 413

Parque Industrial Escobedo Escobedo N.L Mexico 66062 Servicio al Cliente 01-800-849-65-77 www.peerless-av.com

© 2018. Peerless Industries. Inc.