

LED Interactive Multi-Touch Display

User Manual



205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com

V901.20140901Please properly keep the manual for further reference. This is the general user manual for all interactive panels. Therefore, it may be different from the actual product.

Qomo HiteVision, LLC

www.qomo.com

Table of Contents

NOTICE	
Mounting Requirements	5
Bearing	5
Ventilation	5
Introduction	7
Characteristics	7
Outer Appearance	
Interface Panel	
Functions of Remote Controller	
Basic Operation	
Start Up	
Shutdown	
Software Installation	
Software Uninstall	
Software Calibrate	
Assemble OPS Computer	
Smartbar	
Home Page	
Task Manager	21
White Board	
Gallery	
File Manager	
System Settings	
Set Time/Date	
Net State	
Input Method	
Printer	
Language	
Clear Screenshots	
Auto Brightness	
Restore Default Setting	
Browser	
Programs	
Calculator	
Clock	
Music	41
ES File	
Temperature Measuring	
Select Signal Channel	
Menu	43
Picture	
Sound Mode	44

Setting	45
Time	45
Parent Control	46
ECO Mode	
Serial Port Control	47
Specifications of PC Mode (VGA Input)	49
Formats Supported by USB Mode	50
FAQ & Troubleshooting	50
Maintenance Tips	53
Specifications	53

NOTICE



- Install or place components of which power supply voltage is high enough to cause personal injury in places out of the reach of children.
- Do not use any types of power cables other than the one provided together with the product to prevent the product from being damaged.
- Do not open the enclosure unless you are a professional maintenance engineer to prevent an electric shock.
- Check if the electric supply voltage complies with the product's receiving power supply before use.
 Disconnect the product from the power supply if the product is not to be used in a long period of time.
- Use a three-phase power socket and ensure that it is properly grounded.
- Disconnect the product from power supply and stop using it if you sense any abnormal sound or smell emitted by the product. Find a professional maintenance engineer to service it.
- Do not let any liquid and metal object go into the product. If any liquid or metal object goes into the product, cut off the power and find a professional maintenance engineer to handle it.
- Do not place the product on an unstable stand, bracket or table. Otherwise, it may fall off and cause personal injury.
- Move the product carefully to prevent it from being hit or squeezed, especially the display part, which may cause injury if broken.
- Mount the product as instructed and using only mounting accessories recommended by the manufacturer.
- The product can only be mounted on a concrete wall, solid wall and wood plank wall that can bear over three times of the weight of the interactive panel. Ensure proper ventilation. You should assess the bearing capability of the wall before mounting the product on a special wall such as a steel-structure, hollow, glass or marble wall.

Mounting Requirements

Bearing

You can choose the potable or wall mounting method according to your needs. Wall mounting can substantially save the space.

If you choose portable mounting, use the mounting rack or support. If you want to use a self-made mounting rack, the bearing capacity of the rack should be at last four times of the actual weight of the display. The bearing capacity of the mounting support must be at least four times of the actual weight of the display to ensure steadiness of the interactive panel.


When you choose wall mounting, the bearing capacity of the mounting surface must be at least four times of the weight of the display. When the mounting surface is a wall or ceiling of a building, the wall must be built with solid bricks, concrete or materials of equal intensity. If you need to mount the display on a loose surface such as an old brick wall, wood plank wall, solid brick wall, metal or non-metal structure wall, or a wall with a thick decoration layer, take necessary consolidating measures to ensure that the display is steadily mounted.

Ventilation

Ventilation requirements	Distance to the mounting surface (cm)				
Nominal power	Left and right sides	Тор	Bottom	Back	
Larger than 100W	10	20	20	10	

Note: If the product is mounted inside a wall or a cabinet, in addition to the above-mentioned requirements, the area of ventilation holes at the bottom, top and two sides must be at least 50% of the sealing surface to ensure proper ventilation.

Figure:



* See CAS 132-2006


Introduction

Thank you for buying Interactive touch screen. As our latest independently developed and produced human-machine interactive products, the Interactive touch screen are multi-functional teaching displays for interactive teaching, digital demonstration, multi-media presentation, touch operations and handwriting. They are well designed and produced to meet needs of education applications, and provide a user-friendly experience, digital intelligent control as ideal apparatus for modern education. You can use your fingers or opaque objects to write, edit and delete any things on them.

Characteristics


- Specially designed for teaching and meeting systems
- Integrating user management module to realize user adding/deleting, switching and user information customized functions that coincide with users' preference
- Adopting infrared array scanning and sensing technology, HID drive-free, plug-and-play
- Outstanding display edit functions, supporting instant editing
- Multiple optional pens, width and colors; simulative brushes that are vigorous
- Multiple backgrounds, supporting customized background with any images and graphs inserted
- Support dual-point touch and multi-finger roaming; simulative mouse operation
- Supporting identification of handwritten Chinese, English, number and special characters
- Supporting conversion of handwritten files into other formats including PDF, JPEG, GIF, PNG, TIFF and BMP
- Intelligent geometric figure identification, able to identify multiple figures with high recognition rate and multi-pen identification
- Vector-based graphic processing with high compression rate and low distortion
- ECO back-light mode, lower power consumption
- High luminance and contrast display to ensure clear display under straight light or in outdoor environment
- Supporting SD card

Outer Appearance



(Front view)


Control panel



- 1]. HOME: Open the Android home page.
- 2]. RETURN: Go back or return to the parent menu.
- 3]. MENU: Show or hid menu. .
- 4]. ECO: Switch over to ECO, Auto or Standard mode.
- 5]. SOURCE: Show or exit from the list of signal sources.
- 6]. VOL+: Increase the volume.
- 7]. VOL-: Decrease the volume.
- 8]. PC Pwr: Turn on/off the OPS computer.
- 9]. Touch port 1 only supports 2m USB cable.

Interface Panel





Functions of Remote Controller

- On or standby 11. **Mute** 21. 0--9: Select TV channel or enter number 3]. FOME: Open the Android home page. 41. Go back or return to the parent menu. 5]. : Show or hid menu. 61. : Show or exit from the list of signal sources. 71. Enable Alone mode. 8]. · Freeze 91. 10]. Up/Down/Left/Right direction buttons 11]. (Confirm. 12]. CAPTURE: Capture screen shots. 13]. Even the current signal source. You cannot show it in Android. 14]. III: Adjust screen displaying. 16]. E. Change the display mode. 17]. [III]: Turn to the previous page on white board
- 18]. Turn to the next page on white board software and PPT.
- 19]. Open white board software.

software and PPT.

- 20]. Switch over to VGA signal source.
- 21]. Switch over to HDMI signal source.
- 22]. Switch over to OPS computer signal source.
- 23]. Zoom up and down.



Basic Operation

Start Up

- Power the interactive panel with a 100-240V 50/60Hz AC power supply.
- Connect the panel to the power supply. Switch on the rocker switch (on the left of the rear of the panel, next to the power cable port) to enter the standby status. The power LED turns red.
- Press **Power** on the control panel or **Standby** on the remote controller to turn on the interactive panel. The OPS computer is started. The power LED turns green.







Shutdown

- Press **PC Power** to turn off the OPS computer (for all-in-one models only).
- Press **Power** on the control panel or **Standby** on the remote controller to enter the standby status. The power LED turns red.
- Under the standby status, switch off the rocker switch to turn off the interactive panel.

Note:

- 1] Please turn off the OPS computer before the interactive panel. Otherwise, the computer can be damaged.
- 2] Please disconnect the interactive panel from power after the panel enters standby status. Otherwise, the panel can be damaged. A sudden power failure can damage the interactive panel.

Software Installation

• Recommended configuration:

CPU: Inter (R) Core i3 2.27GHz or AMD CPU with equivalent performance

Memory: 1GB

Hard drive: 1GB

Graphics card: supports DirectX 9 or above

- If the interactive panel is equipped with the latest version of handwriting software in the PC before being delivered, please skip the step.
- HID drive-free function only applies for Vista, Windows 70r higher version (realize the functions of multi-touch etc.). The touch LCD display with Windows XP version should install/run the software for normal use.
 - 1. Insert the official USB cable into the USB ports of the computer and touch LCD display.
 - 2. Insert the official software installation disk into the computer.
 - 3. Double click the setup, follow the instructions and complete the installation of the touch LCD display software.
 - 4. The computer needs to restart so as to activate the software after installation completed. Save all the files in the computer and restart.

Software Uninstall

If you are sure to delete the touch LCD display software from your computer, click "Add or Remove Programs" in "Control Panel". Choose "Flow!Works" and click "Uninstall" to uninstall.

Control Panel Home View installed updates Turn Windows features on or	 All Control Panel Items Programs and Features Uninstall or change a program To uninstall a program, select it from the list 				
off	Organize 🔻				
	Name	Publisher	Installed On	Size	Version
	Z Adobe Flash Player 10 ActiveX	Adobe Systems Incorporated	2014/11/3	6.00 MB	10.1.85.3
			2014/11/3 2013/6/11	6.00 MB 126 MB	
	Adobe Flash Player 10 ActiveX	Adobe Systems Incorporated			8.1.0

Software Calibration

To work normally, the handwriting of the projected image on the touch LCD display should coincide with the actual one so as to calibrate accurately. The following situations need calibration.

- When you first use the interactive LCD panel;
- Re-install the drive program;
- When you connect the panel to another PC;

The handwriting panel adopts nine-point calibration method. The position process is described as follows:


① Connect the panel and run the drive program;

Click the handwriting drive icon on the right bottom of the panel to show the following image::

- 1. Connect the display and run the drive program;
- 2. Click the handwriting drive icon on the right bottom of the display to show the following image:



3. Select Nine Points and click Calibrate.




4. Use the pen to click and hold the center of the flickering cross. Do not release it until the flickering cross moves to the next positioning point. Complete the calibration process as instructed. After it completes, you will return to the desktop automatically.



Positioning Method for Windows 7

- 1. Connect the interactive panel to PC using the USB lead via the USB interface on the panel;
- 2. Select Tablet PC Setting on Control Panel.



3. Select

🔒 Calibrate...


on the setting window.

Configure Configure yo displays.	our pen and touch
Display option	ons
Display:	1. Mitsubishi XD435/430/420 👻
Details:	Touch Input Available
Choose the o	Image: Calibrate rder in which your screen rotates.
Go to Orienta	

Use the pen to click and hold the center of the flickering cross. Do not release it until the flickering cross moves to the next positioning point. Complete the positioning process as instructed.

To provide calibration samples, tap the crosshair each time that it appears on the screen. Right-click anywhere on the screen to return to the last calibration point. Press the Esc button to close the tool. Do not change your screen orientation until you have completed the calibration process.	

Click **Yes** after it completes.




💏 Hits & Tips

- To ensure the handwriting accuracy, use the pen provided together with the interactive panel rather a finger to perform calibration.
- Calibration errors may cause touch functions of the interactive panel fail. In that case, please perform positioning again.
- Tap ESC on the keyboard during the positioning process to cease positioning.
- The calibration interface varies between different software versions. Please follow instructions provided on the actual interface.

Assemble OPS Computer

Insert OPS computer into the slot and fasten it with two M4 screws on the left and right.



Note:

The OPS computer is not plug-and-play. Disconnect the interactive panel from the power before inserting the OPS computer.

Smartbar

The smartbar has three modes: Home Page, White Board, and Remarks.

Under any of the three modes, you can click \leftarrow on the toolbar to go back to the previous page and click

to exit from other programs or go back to the home page from other signal sources.

• On the home page, the smartbar is under the home page mode and shows icons of the white board, album, file manager, system setting, browser and listen alone mode. You can click an icon to open the corresponding program.



(Home page mode)

After the white board program is started, the smartbar enters the white board mode, under which you can choose a pen, line and color to write on the white board. Click and select New Page, Overview, Delete or Setting from the menu.



(White board mode)

• In programs other than the white board, the smartbar is in the Remarks mode. You can select a pen, line and color to add notes and remarks on the file opened (including image, PPT and PDF).



(Remarks mode)

Note: Click ▼ on the right to hide the toolbar. Scroll down with your finger to show the smartbar.

Home Page

The home page provides the preview function that displays three items:

- 1] OPS computer preview
- 2] External PC preview such as laptop
- 3] Portable device preview such as flash disk and SD card

Click \bigcirc on the smartbar or Home button to enter the home page and show the preview window. When more than three preview windows are displayed, additional windows will be displayed on the second page. Scroll left and right to turn page.




The following figure shows the interface when a SD card is inserted into an all-in-one interactive panel.

🕼 Temp31°C 🛛 📉	04/01/20	014 13:00	
	老毛桃U盘	HDMI1	
	-		
	< A 🗆 E 🚺	🐻 💽 🌖 🔍	


Click the SD card preview window to open the SD card interface.

Click on the upper left corner of the home page to show tools, clock, calendar and calculator. Click at the bottom to hide tools and go back to the home page.



Task Manager

In the task manager, you can view currently running programs, switch and end programs. Click unter the task manager as shown in the following figure:



• View running programs

In the task manager, scroll left and right to view currently running programs.

Switch programs

In the task manager, click a program to switch over to the program. For example, click **View ES File** to switch over to the ES file program; click **Albums** to switch over to the gallery; and click **File Browser** to switch to the browser program.


End programs

In the task manager, click a program and scroll up and down to end the program, or click a program and hold it for several seconds to show a prompt box. Click **Remove from List** to end the program.

🔞 🕼 Temp30°C 🛛 🗠		04	/01/2014 12:24	PM				
			,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
					NO	SIGNAL		X Arraya Johanna Johanna Arraya Nar Santa
			com.mstar.t		Tvsetting		Settings	
			Remove from li App info	st				
	$\leftarrow $	2		State	5		•	

White Board

The white board provides the writing function. In the white board program, you can select a pen, line and color to write and use eraser to erase content on the white board. You can also print and clear the content on the white board.



• New White Board and Setting

Click and select New Page, Overview, Delete All or Settings from the menu.

		New Page					
	=	Overview					
	=	DeleteAll					
		Settings	-				
\leftarrow		\equiv		Real Provide American Ame American American Am American American A	5	••••	

Click Settings to set the color and shade of the white board.

Pen/Line/Color

If you want to use marker, click and hold for two seconds to set the line and color.




If you want to use highlighter, click and hold Å for two seconds to set the line and color.



Eraser

If you make an error or want to erase something, click 🔳 to use the eraser to erase the content that you want to erase.




Click **f** to show **Print** and **Clear** item. Click Print to print the content on the white board. Click Clear to clear things written on the white board.



Gallery

You can enter the album to view images one by one or as slides.




Click on Smartbar to enter the album to show all folders containing images.

Click a folder to show images contained in the folder.

Single image

Click one image in a folder. Scroll left to show the previous image and right to show the next.

Under the single image mode, you can click icons on upper right corner of the image to delete, cut and edit the image.




♦ Slide

Click on the upper right corner of the folder and select Slide to view images as slides.

File Manager

In fire manager, you can copy, print and view files in the system.

Click on Smartbar to enter the fire manager interface and show the file system. It also shows files in portable devices such as SD card and flash disk.



♦ Copy

Click one file or tick off Multiple and choose several files.

System files				☐ MultiSelect ×
System fil	Music	IMG	Screenshot	
	Notificatio	IMG	Screenshot	
	Pictures	IMG	Screenshot	
-	Podcasts	IMG	Screenshot	
	Ringtones	IMG	Screenshot	Screenshot_2014-04-01-12-23-40.png
-	ScreenIma	IMG	Screenshot	Open
-	temp	IMG	Screenshot	

Click to copy selected files to the portable device.

System files								Multis	Select X
Syster	n fil	Music	IMG	Screenshot					
		Notificatio	IMG	Screenshot					
		Pictures	IMG	Copy to		\times			
		Podcasts	IMG	<u> </u>	SD Card	- 1		Ð	r Ch
		Ringtones	IMG	ourcensnot	_	Screenst	not_2014-04-01-12-:		
		ScreenIma	IMG	Screenshot		Corcentor	Open	,	
		temp	IMG	Screenshot					

•	Print						
	Click 🖨 to open th	ne preview page	e. Click 🔯	to set the printer. Click	- and	+ to set the	
	number of copies to b	be printed. Click	Print	to start printing.			
		Print Preview			\times		
		Current Printer Copies	Image: Print Test Page				
			Cancel	Print			
٠	View						
	Click Open to	o open a file. Y	ou can view fi	les including images, m	nusic, wor	d, PPT and PDI	7.

System Settings

Click construction on Smartbar to enter the system settings page, which includes options including Volume, Date and Time, Network, Input Method, Printer, Language, Clear Screenshot, Auto Brightness, and About Android.


System Settings		\times
叭) Volume	0	
🕭 Date and Time	4/1/14 12:29 PM	>
L. Network	Ethernet Connect	>
End Input Method	Google inputmethod	>
Printer	No Printer	>
A ^a Language	English	>
Auto-cleaning	Two months	>
	Deel Time	

Set Time/Date

Click **Date and Time** to enter the time/date setting interface.

Click Using 24 hour format. When it is grey, it is 12-hour system. You can click AM or PM. When it is green, it is 24-hour system.

Click Auto Update. When it is grey, you can modify the time and date. When it is green, the time and date will be automatically updated by the system.



Click Otto enter the time zone setting interface as follows:

time zone	×
Eastern Time	GMT-4:00
Atlantic Time (Barbados)	GMT-4:00
Manaus	GMT-4:00
Santiago	GMT-4:00
Atlantic Time (Canada)	GMT-3:00
Brasilia	GMT-3:00

After setting, click save to save it. Click < on the upper left corner or Back on the remote controller to go back to the parent menu. Click × to close the current page.

Net State

Click Network to show the Network status, Ethernet, WI-FI and Proxy settings. Choose a network connection method and set parameters accordingly.

< Net state		×
Retwork status	Connect format	
Ethernet setting	Cable network card can not use	
🗢 Wi-Fi setting		
Proxy setting		
🖙 Wi-Fi hotspot		

♦ LAN setting

If the panel is connected with LAN cable and supports Dynamic Host Configuration Protocol (DHCP), the system will automatically configure the network protocol (IP) value.


< Net state			\times
Retwork status	Automa	tic IP Addressing 💶 🔵	
Ethernet setting	IP Address	0.0.0.0	
🗢 Wi-Fi setting	Subnet Mask	255.255.255.255	
Proxy setting	Default Gateway	0.0.0.0	
🖙 Wi-Fi hotspot	First DNS	0.0.0.0	
	Second DNS	0.0.0.0	

If you want to manually set the network protocol, enter the IP address, default gateway, and DNS server parameters on the software keyboard or remote controller. Slide $\frac{1}{2}$ to select the subnet mask to be changed. After setting, click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click × to close the current page.

< Net state		×
Retwork status	Automa	tic IP Addressing 🔵 💿
Ethernet setting	IP Address	0.0.0.0
<section-header> Wi-Fi setting</section-header>	Subnet Mask	2 55 . 255 . 255 . 255
Proxy setting	Default Gateway	0.0.0.0
🖙 Wi-Fi hotspot	First DNS	0.0.0.0
	Second DNS	0.0.0.0

• WIFI setting

When WI-FI is enabled, the system will automatically search available WI-FI access points (AP). You can choose an AP on the list.



If you select an AP with safety authentication, you need to enter the password on the software keyboard on the safety authentication interface.

After setting, click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click × to close the current page.

Proxy


When the proxy server is enabled, you can enter the master and proxy server port numbers on the software keyboard or remote controller.

<	Net state		\times
,	Network status	Use Proxy Server	
	Ethernet setting		
((•	Wi-Fi setting		
C	Proxy setting	(!)	
	Wi-Fi hotspot		

After you enter the master and proxy server port numbers, click **Verify** and enter the username and password. After setting, click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click \times to close the current page.

Input Method

Click Input to show options including ASOP and Google inputmethod. You can choose an input method according to your preference. After setting, click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click × to close the current page.



Click AOSP and configure functions as follows:

🕼 Temp31°C 🛛 🗸	04/01/2014 12:35 PM		
Android keyboard settir	igs		
GENERAL			
	to-capitalization italize the first word of each sentence		
Sc	und on keypress		
TEXT CORR	CTION		
	to-correction acebar and punctuation automatically correct mistyped words		
	ow correction suggestions ays show		
GESTURE T	/PING		
	able gesture typing ut a word by sliding through the letters		
	namic floating preview the suggested word while gesturing		
Sh	ow gesture trail		
OTHER OPT	ons		
Νε	xt-word suggestions	2	

Click Google inputmethod and configure functions as follows:

🕼 Temp31	°C 🗸	04/01/3	2014 12:35 PM		
Google in	putmethod setting				
	Key Volume ^{Off}				
	Associated input				
	English/Chinese Shift-space				
-					

Printer

Click **Printer** to show the printer setting interface. Enter the name, type and IP of the printer. After setting, click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click × to close the current page.

< Printer Settings		×
Name	please enter the printer name	
Printer Type	Generic BW LaserJet PCL5	
qı	Supports LaserJet compatible printers (HP, Canon, Brother, L Xerox). Please enter the default printer ip:172.2	
Queue Type	RAW	
Port	Works with most network printers. 9100	
1	Fest Save	

Language

Click Language to show options including Chinese (Simplified), Chinese (Traditional), and English. Select a language. Click < or **Back** to return to the parent menu. Click \times to close the current interface.

Language setting	\times
✓ English	
中文 (繁體)	
German	
中文 (简体)	


Clear Screenshots

Click **Clear Screenshots** to show options including One Month, Two Months, Three Months, Six Months, and Twelve Months. Select a period. Click < or **Back** to return to the parent menu. Click \times to close the current interface.

< Auto-cleaning	×
One month	
✓ Two months	
Three months	
Six months	
Twelve months	

Auto Brightness

Click **Auto Brightness** to show options including Time delay and Real-Time. Click **Time-Delay** and auto brightness adjustment will be delayed for five minutes. Click **Real-Time** to enable auto brightness adjustment immediately. Click < or **Back** to return to the parent menu. Click × to close the current interface.



Restore Default Setting




Click About Android to show the following interface. Click Reset.

Click **OK** to restore the default setting. Click < on the upper left corner or **Back** on the remote controller to go back to the parent menu. Click \times to close the current page.

< Restore Factory	×
Restore the factory settings list of .Clear Your Google Account .System and application data ar	features (clear all user data on the TV): nd settings
.TV data factory recovery	
	OK
Restore Factor Are you sure you	y restore the factory settings?
ОК	Cancle

Browser

Click On Smartbar to open the web browser. Enter a website and keywords to search on the software keyboard or remote controller.



Programs

Click on the Smartbar to enter the program interface and show all programs in the system. Scroll right and left to turn the page as follows:



(Page 1)


Calculator

Click **to** enter the calculation page. Click numbers and characters on the keyboard.

Temp31°C	C ∂ Temp31°C ∨ 04/01/2014 12:39 PM					
					7>	<8 ≪
sin	In	7	8	9	÷	(
cos	log	4	5	6	×)
tan	е	1	2	3	_	
π	٨					=
!	\checkmark	0			+	

Clock

Click Start to start timing and Stop to stop it.



Music

Click O to start the music program. The system will display songs in the local disk by artists, albums, file names, playlist and playing status.




ES File

Click 📠 to open ES File. You can copy, cut, delete, move and rename files.



Select an image to display and and on the upper right corner of the interface. Click and on the upper right corner of the interface to select a file and click to select all files.



Temperature Measuring

Click **lie** to measure the temperature of the panel.



Select Signal Channel

There are three ways to select a signal channel:

- 1.1 Press **Signal** on the remote controller.
- 1.2 Press **Signal** on the control panel of the interactive panel.
- 1.3 Click 💻 in the Programs page.

Open **Signal** to show the following interface. Press $\blacktriangle / \blacktriangledown$ to select an option and press **OK**. You can also click an icon on the interface.



•Note: The interactive panel will automatically detect signals when it is started or there is no signal.

Menu

Press Menu on the remote control to show the menu (Image \rightarrow Sound Mode \rightarrow Channel \rightarrow Setting \rightarrow Time \rightarrow Parent Control). Scroll left and right on the screen or press $\triangleleft/\triangleright$ to switch between options.

Picture

The Image menu shows options including Picture Mode, Color Temperature, Zoom Mode, Image Noise Reduction, and MPEG Noise Reduction. There are two ways to set it:

- 1.1 Click an icon and set it.
- Press ▲/▼ to move the cursor onto an option. Press OK and press ◄/► to adjust the value. Press Back to quit the menu.

licture		<u> </u>
Picture Mode		soft
Contrast	50	
Brightness	50	
Hue	50	
Sharpness	50	
Saturation	50	
PC Image Mode		
Color Temperatu	re	standard
Zoom Mode	16:9	
Image Noise Red	weak	
MPEG Noise Red	uction	weak
		Menu

Note: When the image mode is **User**, you can adjust the contrast, brightness, hue, sharpness and saturation.

Sound Mode

The Sound Mode menu shows options including Sound Mode, Equalizer, Balance, Surround, SPDIF Output and Alone. There are two ways to set it:

- 1.1 Click an icon and set it.
- Press ▲/▼ to move the cursor onto an option. Press OK and press ◄/► to adjust the value. Press
 Back to quit the menu.

•	•	•	•	•		
	_		=	-	User	
	55					
	45					
	50					
					Off	
					PCM	
						Menu
		45	45	45	45	55 45 50 Off

Note: When the sound mode is set to User, you can adjust High Pitch and Low Pitch.

Setting

The Setting menu shows options including Menu Time, Switch Mode, Color Range, MHL Auto Switch, Movie Mode, and Restore To Default. There are two ways to set it:

- 1.1 Click an icon and set it.
- Press ▲/▼ to move the cursor onto an option. Press OK and press ◄/► to adjust the value. Press
 Back to quit the menu.

Menu Time	10 Seconds
Switch Mode	Black Screen
Color Range	0~255
MHL Auto Switch	Off
Movie Mode	On
Restore To Default	
The machine 0°C temperature:	M

Time

The **Time** menu shows options including **Date**, **Current Time**, **Off Time**, **Scheduled Time**, and **Sleep Time**. There are two ways to set it:

- 1.1 Click an icon and set it.
- Press ▲/▼ to move the cursor onto an option. Press OK and press ◄/► to adjust the value. Press
 Back to quit the menu.



Parent Control

The **Parent Control** menu shows options including **Lock System**, **Set Password**, **Block Program**, and **Lock Children**. There are two ways to set it:

- 1.1 Click an icon and set it.
- Press ▲/▼ to move the cursor onto an option. Press OK and press ◄/► to adjust the value. Press
 Back to quit the menu.

arental	•	•	•	•	•	•		
Lock System	=	-	=	=	=	_	Off	_
Set Password								
Block Program								
Lock Children							Off	
			_					Menu

Note: This menu is only available when TV signal source is used.

ECO Mode


Press **ECO** on the remote controller to enter the ECO mode (ECO-Auto-Standard). Press this button to switch among the three modes.

- The power consumption will be halved under the ECO mode.
- Under the Auto mode, the display will automatically adjust the brightness of the screen according to the light from the environment. When the surrounding light is strong, the screen will bright up. When the surround light is weak, the screen will darken.
- Under the Standard mode, the screen brightness will stay the same.

•Note: To save energy, please switch off the panel when it is used; and switch the panel to Alone when you do not need to watch the display, thus cutting power consumption.

Serial Port Control

The RS-232 port of the interactive panel is defined as follows:



Connect RS-232 port to the PC or controlling device. Enable RS-233 serial port connection and complete the following configuration.

Port: COM1 (Set according to PC or controlling device's port number)					
Bit rate 115200 Odd/even check None					
Data bits	8	Stop bit	1		

The following table lists button controlling codes. The buttons share same functions with corresponding buttons on the remote controller:

Function	Controlling codes	Function	Controlling codes
Power on	7F 08 99 A2 B3 C4 02 ff 01 00 CF	1	7F 08 99 A2 B3 C4 02 ff 01 21 CF
Power off	7F 08 99 A2 B3 C4 02 ff 01 01 CF	2	7F 08 99 A2 B3 C4 02 ff 01 22 CF
Mute	7F 08 99 A2 B3 C4 02 ff 01 02 CF	3	7F 08 99 A2 B3 C4 02 ff 01 23 CF
Touch status	7F 08 99 A2 B3 C4 02 ff 01 03 CF	4	7F 08 99 A2 B3 C4 02 ff 01 24 CF
WIFI	7F 08 99 A2 B3 C4 02 ff 01 04 CF	6	7F 08 99 A2 B3 C4 02 ff 01 26 CF
White board	7F 08 99 A2 B3 C4 02 ff 01 07 CF	7	7F 08 99 A2 B3 C4 02 ff 01 27 CF
Signal source	7F 08 99 A2 B3 C4 02 ff 01 06 CF	8	7F 08 99 A2 B3 C4 02 ff 01 28 CF
Display status	7F 08 99 A2 B3 C4 02 ff 01 09 CF	9	7F 08 99 A2 B3 C4 02 ff 01 29 CF
HD 1	7F 08 99 A2 B3 C4 02 ff 01 0A CF	0	7F 08 99 A2 B3 C4 02 ff 01 2A CF
HD 2	7F 08 99 A2 B3 C4 02 ff 01 0B CF	ОК	7F 08 99 A2 B3 C4 02 ff 01 2B CF
OPS computer	7F 08 99 A2 B3 C4 02 ff 01 0C CF	←	7F 08 99 A2 B3 C4 02 ff 01 2C CF
PC 1	7F 08 99 A2 B3 C4 02 ff 01 0D CF	\rightarrow	7F 08 99 A2 B3 C4 02 ff 01 2D CF
PC 2	7F 08 99 A2 B3 C4 02 ff 01 0E CF	1	7F 08 99 A2 B3 C4 02 ff 01 2E CF
YPbPr	7F 08 99 A2 B3 C4 02 ff 01 10 CF	\downarrow	7F 08 99 A2 B3 C4 02 ff 01 2F CF
Video 1	7F 08 99 A2 B3 C4 02 ff 01 11 CF	Search	7F 08 99 A2 B3 C4 02 ff 01 1E CF
Video 2	7F 08 99 A2 B3 C4 02 ff 01 12 CF	Capture	7F 08 99 A2 B3 C4 02 ff 01 1F CF
Up	7F 08 99 A2 B3 C4 02 ff 01 13 CF	Auto ADJ	7F 08 99 A2 B3 C4 02 ff 01 20 CF

Function	Controlling codes	Function	Controlling codes
Down	7F 08 99 A2 B3 C4 02 ff 01 14 CF	Listen Alone	7F 08 99 A2 B3 C4 02 ff 01 15 CF
VOL -	7F 08 99 A2 B3 C4 02 ff 01 17 CF	ECO	7F 08 99 A2 B3 C4 02 ff 01 16 CF
VOL +	7F 08 99 A2 B3 C4 02 ff 01 18 CF	Model	7F 08 99 A2 B3 C4 02 ff 01 31 CF
Channel -	7F 08 99 A2 B3 C4 02 ff 01 19 CF	Audio mode	7F 08 99 A2 B3 C4 02 ff 01 34 CF
Channel +	7F 08 99 A2 B3 C4 02 ff 01 1A CF	Power status	7F 08 99 A2 B3 C4 02 ff 01 37 CF
Menu	7F 08 99 A2 B3 C4 02 ff 01 1B CF		
Home page	7F 08 99 A2 B3 C4 02 ff 01 1C CF		
Back	7F 08 99 A2 B3 C4 02 ff 01 1D CF		

New search:

DEVICE TYPE	99 A2 B3 C4 02 ff 01 31
VOLUME	99 A2 B3 C4 02 ff 01 33
ECO MODE	99 A2 B3 C4 02 ff 01 35
POWER STATE	99 A2 B3 C4 02 ff 01 37
DISPLAY STATE	99 A2 B3 C4 02 ff 01 32
AUDIO MODE	99 A2 B3 C4 02 ff 01 34
TOUCH STATE	99 A2 B3 C4 02 ff 01 36

Specifications of PC Mode (VGA Input)

SN	Standard	Resolution	Refresh Rate (Hz)	Horizontal Frequency (Khz)	Vertical Frequency (Hz)	Horizontal/Vertical Sync Polarity (TTL)
1	VESA	640X480	60	31.5	60	N/N
2	VESA	640X480	72	37.9	72	N/N
3	VESA	640X480	75	37.5	75	N/N
4	VESA	800X600	56	35.1	56	P/P
5	VESA	800X600	60	37.9	60	P/P
6	VESA	800X600	72	48.1	72	P/P
7	VESA	800X600	75	46.9	75	P/P
8	VESA	1024X768	60	48.4	60	N/N
9	VESA	1024X768	70	56.5	70	N/N
10	VESA	1024X768	75	60	75	N/N
11	VESA	1280X960	60	60	60	N/N
12	VESA	1280X960	75	75.159	75	N/N
13	VESA	1280X1024	60	64	60	P/P
14	VESA	1280X1024	75	80	75	P/P
15	VESA	1600X1200	60	75	60	P/P
16	VESA	1920X1080	60	66.547	59.988	P/P

Formats Supported by USB Mode

Media category	Formats	Extension
Image	JPEG, BMP and PNG	.jpg, .bmp, and png
Movie	MPEG1, MPEG2, MPEG4, H264, RM, RMVB, MOV, MJPEG, FLV	.avi, .mpg, .dat, .vob, .div, .mov, .mkv, .r m, .rmvb, .mp4, .mjpeg, .ts, .trp, .asf, and .flv
Music	WMA, MP3, M4A, (AAC)	.mp3, and .m4a
Text	ТХТ	.txt

FAQ & Troubleshooting

Failure	Possible cause	Solution
Fail to connect to the service program	The drive program is not correctly installed.	Install the drive program correctly.
	The USB interface (lead) is not connected or is faulty.	Change the USB lead or check if the USB interface is faulty.
	The infrared tube is blocked.	Ensure that the surrounding infrared tubes are not blocked.
The panel needs re-positioning every time it is switched on.	The computer is equipped with a recovery card.	Disable computer protection and perform the positioning again.
The positioning is inaccurate.	You do not perform the positioning as instructed.	Press Auto on the remote controller to fully cover the display with an image and use the pen provided together with the panel to perform positioning again.
The cursor of the pen is unstable when the pen is used.	Wrong writing method	Use the pen rather than a finger to write. Grasp the pen as far to the nib as possible. The angle between the pen and display should be larger than 60 degrees. Do not let sleeve or wrist touch the display.
	Strong light or infrared interference	Remove the interference source or change the using environment.
The handwriting is discontinuous.	Wrong writing method	Use the pen rather than a finger to write. Grasp the pen as far to the nib as possible. The angle between the pen and display should be larger than 60 degrees. Do not let sleeve or wrist touch the writing surface.

Failure	Possible cause	Solution
	The required covering area is not reached when writing or the nib is too small.	Change the nib or use a pen with a larger covering area.
	The infrared tube is blocked.	Check if infrared tubes are blocked.
	Strong light or infrared interference	Remove the interference source or change the using environment.
	The color of strokes is same as or similar to the background color.	Change the color of strokes.
Unable to write	You hand or other objects are put on the display when writing.	Use the pen rather than a finger to write. Grasp the pen as far to the nib as possible. The angle between the pen and display should be larger than 60 degrees. Do not let sleeve or wrist touch the writing surface.
	Strong light or infrared interference	Remove the interference source or change the using environment.
	Wrong writing method	Use the pen rather than a finger to write. Grasp the pen as far to the nib as possible. The angle between the pen and display should be larger than 60 degrees. Do not let sleeve or wrist touch the writing surface.
Not sound and image	 Check if the power cable is connected to the power socket and if the panel is connected to power. Check if the rocker switch on the interactive panel is switched on. Check if the Standby button on the panel is pressed. Check if the video and audio input cables are connected correctly. Check if the panel is switched to the right signal source. Check settings including image brightness and contrast. Check the volume. 	
Image is normal, but no sound	 Check the volume. Check if the Mute button on the remote controller is pressed. Check if the audio cable between the PC and interactive panel is connected correctly. 	
No image or the image is black and white	 Adjust color settings. Check the color system. 	
Image or sound is interrupted	 Find out the electric appliance that causes the interference and move it away from the interactive panel. Do not connect the panel to a power socket that a disrupting electric appliance is connected to. 	

Failure	Possible cause	Solution
The remote controller fails.	 Change the batteries. Clean the launch window at the top of the remote controller. (Check if it is blocked) Check contacts of the batteries 	
Computer cannot be started (applicable for models with	 Check contacts of the batteries. Check if the computer adapter is correctly connected and is connected to power. 	
computers)	1	nected correctly to the interactive panel.

Self-inspection:

The following phenomena are not failures:

- Given the high-precision production technology, the LED panel may have a very few constantly bright or dark pixels, which turn out to be tiny red, blue, green or dark points on the panel. The phenomenon is normal.
- The panel may make slight sound when it is adjusting backlight or it is cooling.
- When the image and sound are normal, and you touch the LED panel with fingers, you may feel static electricity. The temperature of the rear of the panel and product is high. These are normal phenomena.

Maintenance Tips

- Do not put or install the product near a heat source or under direct sunlight, in dusty or humid places, or where the product can be affected or damaged by mechanical vibration. To maximize the performance, it should be put away from equipment such as grid, large metal objects and radar stations as far as possible.
- Do not wipe the panel with any chemical agent. Solvents may damage the enclosure or paint. If the panel is stained by dust, please cut off the power, soak the clean cloth in warm water, wring it to clean the panel. You should use a clean soft cloth to clean the LED display of the panel.
- Do not frequently switch on and off the product. This can shorten the product's service life. After the panel is switched off, please wait for three minutes before switching on it again. If the product is not to be used for a long period of time, please disconnect the product from power supply.
- Do not maximize the brightness and contrast of the LED display for a long period of time, which can shorten the LED display's service life.
- Do not write on the touch screen with a hard object, which can scratch the LED display.

Specifications	

Backlight type	LED
Aspect ratio	16:9
Viewing angle	178°
Physical resolution	1920*1080 Pixel
Image/Sound system	PAL/DK, I
Working voltage	AC 90-265V, 50/60Hz
Touch screen material	Tempered glass
Sensing method	Infrared
Technical feature	HID drive-free
Touch point	Multi-touch
Writing method	Fingers or pen
Resolution of touch screen	32767*32767
Communication interface	USB
Storage temperature/humidity	-20°C~60°C, 10%~90%
Working temperature/humidity	5°C~50°C, 10%~90%
Installation method	Wall or portable mounting

- * HiteVision may modify the user manual without prior notice.
- * If you discover any unclear presentation, mistake or omission in this manual, please contact with us immediately. HiteVision is not liable for any loss or damage if you fail to contact with us.

If you want to learn more about our products, please visit our website: www.qomo.com If you need more assistance, please kindly send email to our technical support: support@qomo.com



205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com



28265 Beck Road, Suite C-1 Wixom, MI, 48393, USA Phone: 1-866-990-QOMO (1-866-990-7666) Fax: (248)281-1999(US) or (248)281-1998(International) Sales Information and Quotes: info@qomo.com Literature Request: info@qomo.com Technical Assistance and Service:support@qomo.com