

Technical features

SL100 instrument

Solar irradiation measuring range	from 1 W/m ² to 1300 W/m ²
Energetic exposure measuring range	from 1 Wh/m ² to 500 kWh/m ²
Frequency of measurement	2 / s
Accuracy	5% of measurement
Calculation frequency (W/m ²)	1 / min (average on 60 seconds)
Capacity of measurement (Wh/m ²)	3 days – Results saved when instrument is switched off
Operating temperature	from -10°C to +50°C
Storage temperature	from -10°C to +55°C
Housing dimensions	2.3 x 4.75 x 1.3 inches
Autonomy	more than 72 hours in continuous mode, when using a power supply adapter
Power supply	3 AAA batteries
Electronic	Digital
Electronic board	Varnish
Conformity	in accordance with RoHS directives

Solar cell

Spectral response	from 400 to 1100 nm
Nominal sensitivity	100mv for 1000W/m ² *
Response in cosine	corrected until 80°
Coefficient in temperature	+0.1%/°C
Effective area	1 cm ²
Operating temperature	from -30°C to +60°C
Humidity dependence	100% RH
UV performance	excellent (PMMA filter)
Mode	photovoltaic
Material	polycrystallin silicon
Front face	translucent PMMA
Tightness	Polyurethane resin and housing in PMMA and polyacetol
Cell weight	2.1 oz
Cell dimensions	30 x 32 mm
Cable length	4.1 ft (can be unplugged)



Portable autonomous solarimeter can measure solar irradiation for the control of photovoltaic and thermal installations on test or on site:

- Measurement and spot check of solar power in W/m²

- instantaneous,
- average,
- min./max. values,
- hold function

- Calculation of energetic exposure in Wh/m² during timed dataset *

- Results (Wh/m²) saved when instrument is switched off

SL 100

- Easy to use, for immediate information
- Evaluation of generated electric power, optimum orientation of solar panels, and performances follow-up.
- Choice and determination of thermal or photovoltaic generators features.




For QualiSOL, QualiPV certified professionals, the office control for the Guarantee of Solar Result

Presentation




- ① ② ③ Functions keys
- ④ Delete and Back screen key
- ⑤ Screen key
- ⑥ On/Off key




Settings



Adjust contrast and activate backlight



Calibrate instrument when being returned to laboratory



Remind last checking date



E Instruments International

P: 215-750-1212 F: 215-750-1399 A: 402 Middletown Blvd, Ste 216, Langhorne, PA 19047

www.E-Inst.com