

# **Product Maintenance**

#### **MECHANICS**

Accurate strongly discourages the disassembling of any of its products for maintenance related issues. Please call Accurate with any questions or concerns about lock and hardware functionality.

## When a malfunction is suspected:

- 1. Open door perform all operations (by operating the trim/cylinder). If the lock functions properly, then there probably is an issue with frame preparation.
- 2. If lock does not function while door is open, remove lock from door perform all operations of lock with loose lock and trim.
- 3. If lock has a cylinder operation, check cam compatibility refer to the Accurate catalog or view our Cam Chart.
- 4. If cam is correct and lock still does not function properly, call a technical representative from Accurate.

### **FINISH**

Finish maintenance is a direct function of the type of material, the metal preparation, and the protective agent characteristic of specific finishes.

Please contact Accurate to verify existing finishes and determine appropriate maintenance.

## GENERAL FINISH MAINTENENCE GUIDELINES:

- Finishes with lacquer protective coating: We suggest to use only a non-abrasive moist cloth to wipe the metal. The use of chemical agents is strongly discouraged.
- Finishes without lacquer or any protective coating may be maintained with commercially available products furnished for use with these metals (e.g. Brasso).
- Finishes that include oil protection can be maintained by wiping with a non-abrasive moist cloth, and then applying additional oil in modest amounts with an oil-soaked, non-abrasive cloth.
- Finishes with wax protection can be cleaned with "bowling alley wax" applied in a modest amount by using a non-abrasive cloth.