


REPLACEMENT LENS INSTRUCTIONS FOR CAM 640-GL & CAM 640-PC

EE GP-TP-0001
VIBRA-TITE FASTNER LOCKER TAPE



- 1) REMOVE CAM 421 LENS CAP.
- 2) DISPOSE OF THE OLD CAMERA LENS AND O-RING.
- 3) REMOVE ANY EXISTING TAPE/COMPOUND FROM THE MALE 1-9/16" THREADS OF CAM 224.
- 4) CLEAN ALL PARTS THOROUGHLY TO ENSURE A WATERPROOF SEAL
- 5) WRAP VIBRATITE, VC-3 TAPE 2 TIMES AROUND THE MALE 1-9/16" THREADS OF CAM 224.
- 6) REINSTALL CAM 421 CAP UNTIL IT BOTTOMS ON LENS. TORQUE TO 15ft LBS.