




Claudia looping



Monteringsvejledning/Monteringsanvisning/Montasjeanvisning/Installation instructions/
Installationsanleitung/Asennusohje




Turn power
OFF



Please note:
Serial connection



Turn power
ON






Power supply:

Constant current **350mA**.

Note that the power supply **must be** constant current (350mA) and **not** 12V AC/DC.

Use Scan Products driver – art.no.: 12401, 12402 and 12403.



We refer to our website www.scan-products.com regarding: products, documentation, approvals, dimmer overview, etc.