Manual Supplement

Manual Title: 233 Users Supplement Issue: 4
Print Date: September 2009 Issue Date: 3/11

Revision/Date: Page Count: 2

This supplement contains information necessary to ensure the accuracy of the above manual. This manual is distributed as an electronic manual on the following CD-ROM:

CD Title: 233 CD Rev. & Date: 9/2009 CD PN: 3465353



205 Westwood Ave Long Branch, NJ 07740 1-877-742-TEST (8378) Fax: (732) 222-7088 salesteam@Tequipment.NET



233 Users Manual Supplement

Change #1, 54788

On page 39, under AC Voltage, add note [2] to the Range for 600.0 mV

[2] AC mV is DC coupled.

On page 41, under *AC Current*, replace note [1] with the following:

[1] All ranges are specified from 5 % of range to 100 % of range. AC Amps is DC coupled.

Change #2

On page 2, under Warnings and Cautions, add the following:

- Remove batteries when not in use for two or more months, this reduces the chance of battery leakage and corrosion.
- When your Fluke 233 Digital Multimeter batteries go dead, remove them immediately and replace them with new batteries.

Change #3

On page 35, Table 7, under **Fluke Part or Model Number**:

Change: AC72 To: AC172

Change: TL75 To: TL175

11/10 1

Manual Supplement 233 Users

On page 36, Figure 13:

Change: TL75 Test Lead Set To: TL175 Test Lead Set

Change AC72 Alligator Clips To: AC172 Alligator Clips

Change #4

On page 13, replace the **Battery Saver** section with the following:

Battery Saver™(Sleep Mode)

The Meter powers-down (Sleep mode) if there is no function change, range change, or button push for 20 minutes. The lowest power drain occurs when the display module is docked with the Meter base. When the display is docked and the Meter is in sleep mode or off, a power drain continues from intermittent communication between the radios.

To wake up the Meter, push a button or turn the function switch.

To disable the Sleep mode, hold down the ____ button while turning the Meter on. The Sleep mode is always disabled in the MIN MAX AVG mode.

To optimize battery life, it is recommended one battery be removed from the meter base and display for extended periods of storage or intermittent use.

2 3/11