



INSTALLATION INSTRUCTIONS

PSB-2071

PLASMA DISPLAY MOUNTING BRACKET

Prior to assembly, unpack carton completely and verify contents.

If you are missing any of the following components, please contact Customer Service at 1-800/582-6480



Figure 1

- | | |
|--|---|
| (1) PSB-2071 Bracket | (1) 5/32" Allen Key |
| (4) Mounting Buttons-Black Threaded | (4) 1/4-20 x .5" Button Head Cap Screws |
| (4) 10-24 x .5" Button Head Cap Screws | (4) 1/4 -20 x 1" Button Head Cap Screws |
| (1) 1/8" Allen Key | (4) Nylon Spacers .69" OD x .39" ID x .625" |

BEFORE PROCEEDING, READ INSTALLATION INSTRUCTIONS COMPLETELY

CAUTION! PLASMA DISPLAYS ARE EXTREMELY FRAGILE.

1. Using a 10-24 button head cap screw inserted from back side of bracket, secure mounting button, with chamfered hole of mounting button (larger surface) facing bracket, to bracket (four places) creating a 14" square pattern with the mounting buttons (see Figure 2 & Figure 3).
2. For the Photonics 32" plasma, use the 1/4-20 x .5" cap screws in the slotted holes on the outside edges of the bracket to attach the PSB to the plasma (see Figure 4).
3. For the Photonics 42" plasma, use the 1/4-20 x 1" cap screws in the holes on the inside face in conjunction with the spacers behind the bracket to attach the PSB to the plasma (see Figure 5).
4. With the aid of another person, lift Plasma Display up to the Chief Mount, aligning buttons on the PSB with the teardrop slots in the Chief Mount.
5. Lower safety catch on the Chief Mount to secure Plasma Display, making sure catch is completely engaged.




Figure 2



Figure 3




Figure 4




Figure 5