

VC-DVI Series Quick Installation Guide


1. I would like to install Camera on the desk

1.1 Precautions for installation

- ▶ Please install the machine on a flat desk.
- ▶ Do not grab the camera head by hand when handling the device.
- ▶ Do not rotate the camera head by hand. Improper rotation may result in breakdown of the camera.

1.2 Installation steps

1. Please adjust DIP switch at first prior to installation.
(Please refer to [2. Instruction on DIP SWITCH Setting](#))
2. Place the camera on a flat desk directly to ensure the normal vertical and horizontal operation of the machine.



2. Instruction on DIP SWITCH Setting

2.1 OUTPUT SWITCH



Output Mode	Setting	Output Mode	Setting
1920x1080/60p		1280x720/30p	
1920x1080/50p		1280x720/25p	
1920x1080/30p		1080/59.94p	
1920x1080/25p		1080/59.94i	
1920x1080/60i		1080/29.97p	
1920x1080/50i		720/59.94p	
1280x720/60p		720/29.97p	
1280x720/50p			

2.2 IR SELECT



Setting	Function Descriptions	ID	Setting
DIP 1	Infrared signal output switch OFF: Enable / ON : Disable	1	
DIP 2	Communication baud rate selector OFF: 9600 / ON : 38400	2	
		3	