

Care, Use & Assembly Instructions

34" X 16" HDP (High Density Polyethylene)

Tournament Series Fish Cleaning Station

34" Cleaning station uses "Dual" Magma mounts (See chart below for specific applications).
For level table adjustment, see instructions included with mounting hardware.



WARNING: Do Not install mounting fasteners into table without mount. As they will damage table surface.



Use only provided fasteners. Lost or missing fasteners can be replaced with 1/4"-20 X 1/2" Phillips pan head screws.

Clean with soap and water. For mold / mildew prevention or to disinfect use diluted bleach and water solution. Do not use other solvents or chemicals.


The fish cleaning station is UV stabilized. However when not in use we recommend that you stow away from harsh sunlight.

Note: Prior to mount installation determine specific mount spacing (see mounting hole template). Install mount to table prior to socket installation to verify proper spacing and mount location.


<p>Contents: (1) 34 X 16 HDP Fish Cleaning Station (8) 1/4"-20 X 1/2" Phillips pan head screws (8) 1/4" Washer</p>	<p>Tools Required: (1) Phillips head screwdriver Note: Additional tools and fasteners required for some mount installation.</p>
	



Levelock™ Socket Mounts: T10-522, T10-527



Socket Mounts: T10-521, T10-526
Square Rail Mount: T10-540, T10-640, T10-641
Round Rail Mounts: T10-580, T10-585, T10-590



Round Rail Mount: T10-455

MAGMA[®]

U S A

Magma Products, Inc.
3940 Pixie Avenue, Lakewood, CA 90712 • USA
Phone (562) 627-0500 • mail@MagmaProducts.com
MagmaProducts.com