
Colonial and Chamfered PermaPost® Installation Instructions





2. Remove fastening plates from bottom of post. Trim top of post leaving the pipe flush with the outer shell.



3. If using handrail, check local building codes for minimum rail height. Decide how much is to be trimmed from each end of PermaPost. Top and bottom mounting plates are 1/8" thick. Mark post 1/4" shorter than total opening.



4. Using a hacksaw, trim the post at top and bottom.




8. Position top of post directly under the top fastening plate.




12. Slide skirt into position and caulk seam.





PermaPost[®] Fastener Side View (cutaway)

OPTIONAL FASTENING METHOD, USING PERMAPOST® FASTENING KIT.



HAND RAIL INSTALLATION TIPS:

- Check your local building codes for minimum rail heights for hand rails.
- Ensure that the bottom square portion of PermaPost® will accommodate rail height. Hand Rail must be attached to "square" portion of PermaPost®.
- Pre-drill holes through both the PermaPost® and structural steel pipe prior to attaching hand rail. When attaching hand rail to PermaPost[®], screws must penetrate interior structural steel pipe.

PAINT TIPS:

- PermaPost[®] is made from a low maintenance white polyethylene that is designed to be left unpainted.
- · If painting is desired, follow paint manufacturer's recommendations for painting polyethylene surfaces.
- · Do not paint using dark colors. Dark colors are considered any color that falls within the L value of 56 to 0. "L" is a measure of lightness of an object, & ranges from 0 (black) to 100 (white).




www.hbgcolumns.com Phone: (800) 264-4HBG



5. Fasten one plate, edges down, to the beam above,



9. Position bottom of post over bottom fastening plate.



10. Check post for level and remove temporary support.











3. Fasten one plate (two halves), edges down, to the beam above. Using a plumb tool, find and mark bottom position on floor



6. Position bottom of post over bottom fastening plate.



1. Remove foam block insert from bot-tom. Retrieve fastening plates



4. Fasten the other plate (two halves), edges up, to the floor.



5. Position top of post directly under the top fastening plate.

WARRANTY IS VOID IF INSTALLATION INSTRUCTIONS ARE NOT FOLLOWED

EFFECTIVE DATE: AUGUST 2, 2024





