

### INSTALLATION INSTRUCTIONS

Copy Part# 180016, Rev. B, 02/2014

Page 1 of 1

## Hynaulic

# 5/16" O.D. NYLON TUBE FITTING

- 1 Cut tubing using a tube cutter, leaving the cutoff end as square as possible.
- 2 Slip the nut over the tubing end—(nut should slide freely).
- 3 Push the lock over the end of the tubing and move it back at least one insert length from the end. The lock may slide on freely or require a light press or screw-on action. (The lock has a left hand thread)
- 4 Install the seal over the end of the tubing and against the lock. Refer to Caution.
- **5** Then force the insert into the end of the tubing by pushing it against a clean, flat surface.
- 6 Push the nut and the lock by hand toward the end of the tube as far as possible.
- 7 Insert the tube end assembly into the proper cavity and tighten it down. Tighten only to a solid feel on the wrench.

### A CAUTION

Ensure the seal is not twisted during installation.

#### **A** CAUTION

Extreme care MUST be taken to avoid any contamination from entering the tubing. Failure to do so may lead to system failure.




Figure A.