

MUSTEE UTILITY WALL SINK

INSTALLATION INSTRUCTIONS





- 1. Position tray on wall with mounting holes located approximately 35 1/2" above the floor (Refer to rough-in illustrations above).
- 2. Making sure tray is level, mark the location of the 3 mounting flange holes onto the wall. Using these marks as guides, drill pilot holes to accept 1/4" x 2" lag screws (not provided). NOTE: If installing into cement/masonry walls, use plastic wall anchors.
- 3. Using three (3) 1/4" x 2" lag screws (not provided), securely fasten tray to wall thru rear mounting flange. Use 1/4" dia. flat washers under the heads of the lag screws to prevent damaging the surface of the tray.
- 4. For additional structural support, the two bottom mounting tabs may be used to further secure the trav as shown in FIG. 1.
- 5. Make final plumbing connections in compliance with local code requirements.

CLEANING NOTE:

Most stains that you may acquire in your Model 16 Laundry Tray may be removed with common household cleaner or liquid cleanser. Stubborn stains may be removed with a bleach solution-follow bleach manufacturers recommended procedures pertaining to safety, handling and use of their product.






FIG. 1