ORDERING INFORMATION

VA301C Controller

- ⊠ 301-C □ 301-C-DLC
- Gas detection controller with display and plastic housing.
- Gas detection controller with data logging, display and plastic housing.
- □ 301-C-DLC-BIP
- Gas detection controller with data logging and display, BACnet/IP output and plastic housing.

SPECIFICATIONS VA301C and VA301CDS (same if not specified)

Power Requirements:	17 -27 Vac, 50 or 60 Hz	
Tower Requirements.	24 - 38 Vdc, 500 mA	
Operating Environment:	Indoor Use	
Operating Temperature Range:	-4°F to 122°F (-20°C to 50°C)	
Operating Humidity Range:	0 to 95% RH, (non-condensing)	
Operating Altitude:	Up to 9843 feet (3,000 m)	
Network Capacity:	Up to 96 transmitters, 32 per channel	
Network Capacity.	Channel 1 and 2: Modbus & Vulbus	
	Channel 3 : Modbus only	
	Channel 4 : Slave communication	
Communication	(i.e.: for BACnet option)	
Communication	Up to 2,000 fact (600 m) non shannal	
(length of lines):	Up to 2,000 feet (600 m) per channel	
	T-tap: 65 feet (20 m) maximum per t-tap	
User Interface:	130 feet (40 m) total	
User Interface:	Graphic 122 x 82	
	dot matrix backlit display	
Visual Indicators:	User friendly keypad Power On Green LED	
visual indicators:	Alarm A Red LED	
	Alarm B Red LED	
	Alarm C Red LED	
	Fault Amber LED	
	Tx Amber LED	
	(blinks when in use)	
	Rx Green LED	
	(blinks when in use)	
Outputs:	4 DPDT relays	
o alpato.	5A, 30 Vdc or 250 Vac (resistive load)	
Audible Alarm:	65dBA at 3 feet (1 m)	
Time delays:	0, 30, 45 sec and	
	1 to 99 min.before/after delay	
Battery:	Lithium Battery 3 Volts	
Enclosure VA301C:	NEMA 4X, ABS - Polycarbonate,	
	Indoor use	
Enclosure VA301CDS:	Cast Aluminium #A356.0T6	
Overvoltage category:	II	
Pollution degree:	2	
Dimensions VA301C:	7.99" (H) x 11.02" (W)x 2.76" (D)	
	(20.3cm x 28 cm x 7 cm)	
Dimensions VA301CDS:	9,50" (H) x 14,00" (W) x 3,5" (D)	
	(24 cm x 36 cm x 9 cm)	
Weight VA301C:	2.4 lbs (1.1 Kg)	
Weight VA301CDS:	11,4 lbs (5.2 Kg)	
	-	


INSTALLATION INSTRUCTIONS

Installation instructions must be strictly followed to ensure the proper functioning of the equipment. Honeywell Analytics will not be liable or responsible for any malfunctions or incidents that may occur from improper installation:

- Place each unit in a location that is easily accessible for service
- Avoid placing units near sources of vibrations.
- Avoid placing units near equipment that emits electromagnetic interference.
- Avoid any location where there are large temperature swings.
- Before installing, verify all local codes, standards or legislation that could impact choice of installation location.

WALL MOUNT INSTALLATION





WIRING DETAILS

Power :

The power requirement range is 17-27 Vac, 24-38 Vdc, 500 mA. In both AC or DC mode, the polarisation is not important. The system must be grounded on the transformer. A dedicated circuit-breaker should be used.

Communication:

The communication cables have to be grounded using the shield terminal. Use twisted and shielded Belden cable 24 AWG # 9841 for the connection. The network can be up to 2000 feet (600 m) per channel. The lenght of a T-tap can be a maximum of 65 feet (20 m). A maximum of 130 feet (40 m) for all the T-tap must be respected.

Relay Output:

The relay output will withstand up to 5 A at 30Vdc or 250Vac (resistive load only). They can be used to activate horns and strobes. Refer to drawing below for proper wiring. Each relay can be configured in the programming menu. Default setting is :

Relay 1 (J25) = A Relay 2 (J26) = B Relais 3 (J3) = C Relay 4 (J7) = Fault 5 A, 30 Vdc or 250 Vac (resistive load)

□ <u>BACnet/IP MODULE (-BIP option)</u>

Specifications Ethernet Port :	10/100-compa	tible with 10Base-T interface, RJ-45
Visual Indicators :	Green LED Yellow LED	LINK ACT

DATALOGGER (-DLC option)

The DLC option for the controller collects data automatically and stores it on a digital flash Multimedia Card (SDcard). If ever the SDcard gets full;

- the information logging is stopped
- no SDc flag is diplayed on the screen
- the SDcard LED blinks

WARRANTY AND LIMITS OF LIABILITY

Honeywell Analytics Inc. warrants to the original purchaser that its product, and the component parts thereof, will be free from defects in workmanship and materials for a period of one year from the date of purchase. Honeywell Analytics will, without any charge and at its option, repair or replace defective products or components upon their delivery to its Repair and Service Department. This warranty does not apply in the event of misuse or abuse of the product, or as a result of unauthorized alterations or repairs. Honeywell Analytics shall not be liable for any consequential damages, including, without limitation, damages resulting from loss of use. Every precaution for accuracy has been taken in the preparation of this manual. However, Honeywell Analytics neither assumes responsibility for any omissions or errors that may appear, nor liability for any damages that may result from the use of the products in accordance with the information contained in this manual.

To obtain warranty service, return the product, along with a complete description of the defect, transportation prepaid. Honeywell Analytics assumes no risk for damage in transit. Following warranty repair, the product will be returned to the buyer, transportation prepaid.