



Outdoor Left Side Loveseat CO6260



PART LIST




HARDWARE LIST

#1	#2	#3	#4	#5
		0		
M6*12mm	M6*30mm	M6*35mm	M6mm	M6mm
Bolt 1 PC (Extra 1)	Medium Bolt 4 PCS (Extra 1)	Long Bolt 4 PCS (Extra 1)	Flat Washer 9 PCS (Extra 1)	Allen Wrench 1 PC


Step 1. Lay left arm panel (part D) down on a soft flat surface, such as carpet, as shown below. Attach seat panel (part B) to left arm panel (part D) using medium bolts (part #2), flat washers (part #4) and allen wrench (part #5).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2. Attach back panel (part A) to left arm panel (part D) and seat panel (part B) using bolt (part #1), long bolts (part #3), flat washers (part #4) and allen wrench (part #5).


NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 3. Attach right arm panel (part C) to back panel (part A) and seat panel (part B) using medium bolts (part #2), long bolts (part #3), flat washers (part #4) and allen wrench (part #5).



Step 4. Insert core of seat cushions (part F) into cover of seat cushions (part E). Insert core of back cushions (part H) into cover of back cushions (part G).



Step 5. Carefully turn unit upright and add cushions as shown below.



Step 6. Use straps (part I) to secure additional units together as shown.

