




## Acrylic Tub Installation Instructions

### Starting Point:

- Uncrate your tub and inspect it for any damage. If you have any concerns please contact Magnus Home Products toll free at (833)482-6828
- Adhere to your plumbing and building codes that provide regulations and a set of laws for inspection and installation.
- Seek a professional plumber if you are not familiar with the installation of plumbing and fixtures.

### Rough-In:

- Make sure to use the correct rough-in for your tub (with or without an overflow).
- Utilize the tub's specification sheet found on the Magnus Home Products website page for pre-planning your layout. The specification sheet can vary +/- 1/2".
- If you are installing in a tight space we recommend having the tub on-site for rough-in measurements.



### Clawfoot Installation:

- If the feet are already installed on the tub move to the next step.
- If the feet are not installed refer to the installation guide.

### Drain Installation:

- Install the drain to the tub. Use 100% neutral cure silicone.
- Attach the tub drain to the house drain line. Drain should have been pre-roughed-in.

### Test:

- Fill tub with water and test the tub and drain for any leaks.
- Use built-in adjusters to level the tub and maintain the smallest gap possible between the tub and the finished floor.
- Once the tub is level, apply 100% neutral cure silicone around the perimeter.
- Allow the silicone to cure for 24 hours.

### Cleaning:

- For cleaning wash the tub with mild soap and water only. DO NOT use any abrasive cleaning materials or cleaning pads. Vinegar can be used to tackle the hard water stains and mildew.

### Scratch Removal:

- Using a circular motion, use a wet 1200 grit sandpaper and buff the area of concern.
- To keep a glossy finish buff the tub every 3 months with a white polishing compound.



## Tub Feet Installation With Bar

### Parts Included:

- 2 bars
- 4 mounting bolts
- 4 flat washers
- 6 locking washers
- 6 nuts

A. Roll-top tubs have the drain located at the end of the tub and tilt toward the drain so the two tallest feet must be attached on the end without the drain. The two shortest feet must be attached on the drain end.

B. Double roll-top and double-slipper tubs have the drain located in the center of the tub so no tilt is necessary as the bottom is slanted toward the drain. All four feet should be the same.

1. Place tub upside down onto a soft cloth/blanket to prevent damage. (Note: For roll-top tub slide 2X4 wooden block under rim to elevate the tub from one side. This will help when turning the tub over).
2. Once the tub is turned upside down remove washers and nuts from the threaded studs.
3. Position mounting bars over the threaded studs on both ends.
4. After bars are in place thread a washer and nut onto each stud by hand. Do not tighten until foot is attached. (Shown in image 1)
5. Attach feet onto the bars using flat washer, locking washer and bolt. (Shown in Image 2)
6. Finish tightening the bars once the feet are attached securely (DO NOT OVER-TIGHTEN; MAY CRACK THE TUB).
7. Lift tub by the rim and turn onto its feet. If tub is not level use built-in adjuster under the foot.( DO NOT LIFT TUB BY FEET).



## Tub Feet Installation Without Bar

### Parts Included:

- Rubber Shims (If Included)
- 4 Dovetail Bolts
- 4 Flat Washers
- 4 Locking Washers
- 4 Nuts

A. Roll-top tubs have the drain located at the end of the tub and tilt toward the drain so the two tallest feet must be attached on the end without the drain. The two shortest feet must be attached on the drain end.

B. Double roll-top and double-slipper tubs have the drain located in the center of the tub so no tilt is necessary as the bottom is slanted toward the drain. All four feet should be the same.

1. Place tub upside down onto a soft cloth/blanket to prevent damage. (Note: For roll-top tub slide 2X4 wooden block under rim to elevate the tub from one side. This will help when turning the tub over).
2. Once the tub is turned upside down slide a dovetail bolt into each mounting pod. (Shown in image 1)
3. Put foot onto the dovetail bolt. Secure foot by using locking washer and nut. (It is normal to have small gaps between foot and tub wall).
4. Lift tub by the rim and turn onto its feet.
5. Loosen the bolts and let the tub settle into place on the feet. Tighten the bolts.
6. If tub is not level use built-in adjuster under each foot. (DO NOT LIFT TUB BY FEET).



## Freestanding Acrylic Tub Installation Instructions

BE SURE TO REINFORCE THE FLOOR BEFORE SECURING TUB. WE RECOMMEND (2) 2"x12"s SECURELY FASTENED TO FLOOR BEAMS WHERE YOU PLAN TO SECURE YOUR TUB.

### Stabilize Tub to Prevent Sliding

#### OPTION 1

With tub and drain installed and water tested, add neutral cure silicone around tub base to secure tub to finished floor.

#### OPTION 2

1. Place tub in intended position on floor.
2. Use pencil to trace around tub on floor.
3. Move tub to the side to allow work space.
4. Place wooden blocks on floor inside traced pattern of tub. Blocks can be secured to floor using screws or liquid nails.
5. Put tub back into position over wooden blocks. Wooden blocks will not be visible and will prevent tub from sliding across floor.
6. Once the tub is in position and secure, apply small bead of sealant around the base.

---

## Clawfoot Acrylic Tub Installation Instructions

#### Parts Included:

- (2) 2"x12" boards
- 4 lag bolts
- 4 flat washers

BE SURE TO REINFORCE THE FLOOR BEFORE SECURING TUB. WE RECOMMEND (2) 2"x12"s SECURELY FASTENED TO FLOOR BEAMS WHERE YOU PLAN TO SECURE YOUR TUB.

### Anchor Tub to Floor

1. Place tub in intended position on floor.
2. Mark foot anchoring locations on floor with pencil.
3. Move tub to the side to allow work space.
4. Drill starter holes in floor.
5. Put tub back into position.
6. Place flat washers on lag bolts.
7. Put lag bolts through slot in bottom of foot and screw into floor using wrench or socket.

[www.magnushomeproducts.com](http://www.magnushomeproducts.com)

PH: (833)482-6828

10/12/2017