



** Denotes color.

Note: For bulk packaged TG style jack modules, add -24 to end of part number.

9 T568B Wiring

Color Key: R (Blue), B (Orange), F (Brown), A (Green)

Method 1: Insert wires into the jack, then use a punch-down tool to secure them.

Method 2: Use a screwdriver to push the wires into the jack terminals.

Incorrect wiring configurations are shown with red 'X' marks.

9 T568A Wiring

Color Key: R (Blue), B (Orange), F (Brown), A (Green)

Method 1: Insert wires into the jack, then use a punch-down tool to secure them.

Method 2: Use a screwdriver to push the wires into the jack terminals.

Incorrect wiring configurations are shown with red 'X' marks.

10

11

12

EGJT

REMOVAL STEPS

1

2

3

Notes:

1. For specified performance, follow TIA/EIA 568-C installation guidelines.
2. Jack modules can terminate 22-26 AWG solid or stranded IWC data cable with 0.062" (1.57mm) maximum insulated conductor outside diameter.
3. Jack modules may be re-terminated a minimum of 20 times.
4. For technical and performance information, consult Panduit technical support.

As with all Communication Components, the following statements apply:

1. Never install communications wiring during a lightning storm.
2. Never install communications wiring in wet locations unless the jack is specifically designed for use in wet locations.
3. Never touch uninsulated communications wiring or terminals unless the communication line has been disconnected at the network interface.
4. Use caution when installing or modifying communication wiring.

For Instructions in Local Languages
and Technical Support:
www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

E-mail:
techsupport@panduit.com

Phone:
866-405-6654