


Lock Functions	A	B	C	D	E	F
8800USD-ADL	●			●		
8801USD*						●
8802USD*			●			●
8803USD*		●				●
8822USD	●		●	●	●	●
8824USD	●	●		●	●	●
8825USD	●			●	●	●
8839USD	●	●		●	○	●
8842USD	●		●	●	●	●
8845USD	●			●	●	●
8845SUSD	●			●	●	●
8848USD	●			●	●	●
8849USD	●	●		●	●	●
8856USD	●			●	●	●
8858USD	●		●	●	●	●
8859USD	●			●	●	●
● Required Holes						
○ Optional Holes						

(no strike needed)



Flat or standard bevel (up to 3 1/2°)

"A"
Knob or Lever
hole 3/4" Ø

"B"
Inside Thumbturn
Hole 5/8" Ø

"C"
Inside Cylinder
Hole 1 1/4" Ø

1.125
Min. after
backset

1
Insert Backset
1 1/2", 1 3/4", 2", 2 1/4"

3
4-places

6.250

.750

.750

.312

7.250

8.000

+0.01
-0.00

1.125

.937

.187 Rad.
or Square

+0.015
-0.00

1.250

.218

"D"
Knob or Lever
Hole 3/4" Ø



"E"
Outside ER/
indicator
Hole 5/8" Ø

"F"
Outside Cylinder
Hole 1 1/4" Ø

€ of Lock

€ of Strike

R.125
or Sq.



Notes:

- ▲ Insert backset here 1 1/2", 1 3/4", 2", 2 1/4"
 - ▲ ASA strike 3/8" BELOW centerline of lock. **NOTE: use template #T-ALH.ASADB.STK for #s 8801,8802 and 8803**
 - ▲ Prep for #12 wood or 12-24 machine screws
 - ▲ Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details.
- Accurate lock's accommodates 1 1/2" to 1 13/16" center to centers and up to 1 1/4" dia. post.
If there are any additional questions about the thru-bolting, please contact our office.
- ▲ Knob, thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) Please contact us if a double lip strike is needed - for a proper template
- c) See catalog / spec sheets for additional lock details



ACCURATE
LOCK & HARDWARE
AMERICAN CRAFTED SINCE 1972

Standard 8800USD - Upside Down
(Lever High) Template
All Backsets

T-ALH.8800USD