


Functions	A	B	C	D	E	F
9100ADL	●	●	●	●	●	●
9122	●	●	●	●	●	●
9124	●	●	●	●	●	●
9124RL	●	●	●	●	●	●
9125	●	●	●	●	●	●
9125RL	●	●	●	●	●	●
9134	●	●	●	●	●	●
9139	●	●	●	●	●	●
9142	●	●	●	●	●	●
9143	●	●	●	●	●	●
9143E	●	●	●	●	●	●
9144	●	●	●	●	●	●
9144E	●	●	●	●	●	●
9145	●	●	●	●	●	●
9145S	●	●	●	●	●	●
9146	●	●	●	●	●	●
9148	●	●	●	●	●	●
9149	●	●	●	●	●	●
9153	●	●	●	●	●	●
9149	●	●	●	●	●	●
9156	●	●	●	●	●	●
9158	●	●	●	●	●	●
9159	●	●	●	●	●	●
9160	●	●	●	●	●	●
9167	●	●	●	●	●	●
9169	●	●	●	●	●	●

- Required Holes  
○ Optional Holes

(no strike needed)

## INSIDE OF DOOR

## OUTSIDE OF DOOR



### Important Notes:

- Insert backset here 2 $\frac{1}{2}"$ , 2 $\frac{3}{4}"$ , 3 $\frac{3}{4}"$ , 5", 6"
- ASA strike mounted  $\frac{3}{8}"$  ABOVE centerline of lock
- Prep for #12 wood or 12-24 machine screws (Lock and Strike)
- Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details.

Accurate lock's accommodates  $1\frac{1}{2}"$  to  $1\frac{11}{16}"$  center to centers and up to  $\frac{1}{4}"$  dia. post. If there are any additional questions about the thru-bolting, please contact our office.

Knob/Lever, Thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

### Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) Please contact us if a double lip strike is needed - for a proper template
- c) See catalog / spec sheets for additional lock details

# ACCURATE

## LOCK & HARDWARE

AMERICAN CRAFTED SINCE 1972

### Standard 9100 Lever x Lever or Knob x Knob Template

### All Backsets

T-ALH.9100.LL