




ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY INSTALLATION INSTRUCTIONS




ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY INSTALLATION INSTRUCTIONS


PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


ZINTRA STICKS - (16) WIDE OR (32) NARROW



(16) STANDARD ALUMINIUM TUBE WITH NOTCHES



ZINTRA STICKS - LANDSCAPE EXTERNAL CORNER - (8) WIDE OR (16) NARROW



ZINTRA STICKS


EXTERNAL CORNER LANDSCAPE ASSEMBLY

INSTALLATION INSTRUCTIONS


YOU WILL NEED

(32) SUITABLE SCREWS


SCREWS ARE NOT INCLUDED - INSTALLER TO SUPPLY BASED ON FIXING SUBSTRATE




SPIRIT LEVEL




DROP SAW WITH SUITABLE BLADE FOR ALUMINIUM CUTTING



DRILL



TAPE MEASURE



ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY

INSTALLATION INSTRUCTIONS

STEP 1

MEASURE THE HEIGHT [X] OF THE INSTALL AND CUT THE ALUMINIUM TO SUIT



NOTE: AFTER MEASURING AND MARKING WHERE TO CUT THE ALUMINIUM TUBE, COUNT THE NUMBER OF NOTCHES TO ENSURE IT WILL SUIT THE QUANTITY OF STICKS REQUIRED. FOR EXAMPLE, A WIDE STICK USES 4 NOTCHES, THEREFORE THE NOTCHES IN THE ALUMINIUM TUBE WILL NEED TO EQUAL A MULTIPLE OF 4.

USE A LASER LEVEL OR SPIRIT LEVEL TO MARK ALUMINIUM POSITION ON THE WALL.

IT IS BEST TO START FROM THE CORNER OF THE WALL AND WORK OUTWARDS.

THE FIRST (2) ALUMINIUM TUBES ARE LOCATED 38.1mm [1.5"] FROM THE CORNER OF THE WALL TO THE TUBE CENTRE (1 ON EACH SIDE) AS SHOWN.

PLAN VIEW



STEP 2



CONTINUE MARKING TUBE LOCATIONS ALONG THE WALL AT A MAXIMUM OF 450mm [17.71"] CENTRE SPACING (THIS IS ADJUSTABLE TO SUIT WALL SUPPORT/STUD LOCATIONS IF REQUIRED)

MAX DISTANCE FROM FIRST TUBE CENTRE TO SECOND TUBE CENTRE IS 53.54mm [2.1"]

NOTE: TUBES CAN BE SHARED BETWEEN STICKS AT THE STICK JOIN TO HELP HOLD THE JOIN TOGETHER.

MAX DISTANCE BETWEEN END OF STICK AND TUBE CENTRE (CANTILEVER SPAN) IS 150mm [5.9"]

PLAN VIEW



ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY

INSTALLATION INSTRUCTIONS

STEP 3


DRILL HOLES IN ALUMINIUM TUBES IN LOCATIONS TO SUIT SUPPORT IN WALL (STUD LOCATION ETC)

SCREW ALUMINIUM TUBES TO WALL

DRYWALL SURFACE: USE DRYWALL ANCHOR AND SUITABLE SCREW


TIMBER SURFACE: USE SELF TAPPING TIMBER SCREW

MASONARY SURFACE: USE MASONARY ANCHOR AND SUITABLE SCREW







STEP 4

FOLD ZINTRA STICKS - (16) WIDE OR (32) NARROW



FOLD ZINTRA STICKS - LANDSCAPE EXTERNAL CORNER (8) WIDE OR (16) NARROW



ZINTRA STICKS


EXTERNAL CORNER LANDSCAPE ASSEMBLY

INSTALLATION INSTRUCTIONS


STEP 5

INSERT EXTERNAL CORNER PIECES INTO
THE CORNER ALUMINIUM TUBE NOTCHES

NOTE HOW THE STICK 'SHARES' A TUBE WITH
THE NEXT SET - THIS WILL HELP KEEP
THE STICKS ALIGNED



SIDE VIEW





ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY


INSTALLATION INSTRUCTIONS

STEP 6


INSERT ALL STICKS INTO ALUMINIUM TUBES
AS SHOWN BELOW



A



B



ZINTRA STICKS

EXTERNAL CORNER LANDSCAPE ASSEMBLY INSTALLATION INSTRUCTIONS

FINISHED INSTALL

