



PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


8in MAIN BEAMS (96in) - x2



8in CORNER BEAM - x4



8in BEAM CONNECTOR - x6



BEAMS CLIP - x20




STEP 1

BEAMS ASSEMBLY

ASSEMBLE INDIVIDUALS PARTS AS PER PURCHASED PACKAGE.


FOLD 8IN MAIN BEAM AND SECURE IT BY INSERTING BEAMS CLIPS INTO PRE-CUT RECTANGULAR HOLES.



*BEAMS CLIPS QTY FOR 8IN MAIN BEAMS - x6

*IMPORTANT: DO NOT INSERT CLIPS INTO FIRST AND LAST HOLES OF THE MAIN BEAM


FOLD 8IN CORNER BEAM AND SECURE IT BY INSERTING BEAMS CLIPS INTO PRE-CUT RECTANGULAR HOLES.



*BEAMS CLIPS QTY FOR 8IN CORNER BEAM - x2

*IMPORTANT: DO NOT INSERT CLIPS INTO FIRST AND LAST HOLES OF THE BEAM

FOLD 8IN BEAM CONNECTOR AND SECURE IT BY INSERTING INTO PRE-CUT RECTANGULAR HOLES.



STEP 2


8IN BEAMS CONNECTOR INSTALL

2.1 INSERT 8IN BEAMS CONNECTORS INTO THE ENDS OF 8IN MAIN BEAMS AS SHOWN.

2.2 WITH THE HELP OF FINGER RISE THE TOP OF 8IN MAIN BEAM FOR EASY INSERT.

2.3 INSERT THE 8IN BEAMS CONNECTOR INTO THE CORRESPONDING PRE-CUT RECTANGULAR HOLES IN THE 8IN MAIN BEAM.

2.4 REPEAT STEPS 2.1 - 2.3 FOR EACH 8IN BEAMS CONNECTOR UNTIL THE ASSEMBLY AS SHOWN HAS BEEN COMPLETED.



STEP 3

8IN CORNER BEAMS INSTALL - FINISING INSTALL

3.1 INSERT 8IN BEAMS CONNECTORS INTO THE ENDS OF TWO 8IN CORNER BEAMS AS SHOWN.

3.2 JOINT TWO CORNER BEAMS TOGETHER. USE 2.2 AND 2.3 STEPS FOR CORNER BEAMS INSTALL.

3.3 INSTALL CORNER BEAM SET INTO THE ENDS OF 8IN MAIN BEAMS AS SHOWN. USE STEPS 3.1 - 3.2.

3.4 USE STEPS 3.1 - 3.2 FOR EACH 8IN CORNER BEAMS SET INSTALL UNTIL THE ASSEMBLY AS SHOWN HAS BEEN COMPLETED.

