


ZINTRA EMBOSSED WALL PANELS

ADHESIVE FIX INSTALLATION INSTRUCTIONS

These are 10 different emboss styles.


Sample shown for reference




CORDUROY




JUNGLE




TAPESTRY




SANDGLASS



CONSTELLATION




CUMULUS




TIDAL



DAMASK



LINKED



MOLECULAR

ZINTRA EMBOSSED WALL PANELS


ADHESIVE FIX INSTALLATION INSTRUCTIONS

PARTS & HARDWARE

PANEL



MEASUREMENTS



Wall Panels	Trimmed Size	Trimmed Pattern match size
Constellation	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim
Corduroy	1037mm[40.8"]x 2743.2mm[108"]	Same as Full Sheet Trim
Cumulus	1117.6mm[44"]x 2743.2mm[108"]	1117.6mm[44"] x 2594.82mm[102.15"]
Damask	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim
Jungle	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim
Linked	1117.6mm[44"]x 2743.2mm[108"]	1117.6mm[44"] x 2691.6mm[105.97"]
Molecular	1117.6mm[44"]x 2743.2mm[108"]	1117.6mm[44"] x 2607mm[102.68"]
Sandglass	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim
Tapestry	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim
Tidal	1117.6mm[44"]x 2743.2mm[108"]	Same as Full Sheet Trim


NOTE:

All Trimmed sizes will match **East** and **West**.

Due to the organic design, some panels have to be trimmed **North** & **South** to match on the top and bottom (see table above).

Cumulus Top & Bottom Cut Dimensions

Ensure Panel is facing the right way, prior to trimming




Linked Top & Bottom Cut Dimensions

24.52mm
[1"]

2691.87mm
[105.97"]

26.81mm
[1.05"]




Ensure Panel is facing the right way, prior to trimming

Molecular Top & Bottom Cut Dimensions

Ensure Panel is facing the right way, prior to trimming

2608.14mm
[102.68"]

135.06mm
[5.32"]



ZINTRA EMBOSSED WALL PANELS

ADHESIVE FIX

INSTALLATION INSTRUCTIONS

YOU WILL NEED

SPIRIT LEVEL




TAPE MEASURE



LOCTITE POWER GRAB HEAVY DUTY CONSTRUCTION ADHESIVE OR PATTEX PL200




APPROPRIATE APPLICATOR



STANLEY KNIFE

OR

JIGSAW WITH BOSCH T313AW3
KNIFE BLADE



ZINTRA EMBOSSED WALL PANELS


ADHESIVE FIX

INSTALLATION INSTRUCTIONS

STEP 1


Be certain that your substrate will hold an adequate bond to the recommended adhesive(s). If in doubt about a coating or a finish already in place, an adhesion mock up test is recommended before you begin.

Cut, scribe and dry pre-fit all Zintra panels as necessary.



STEP 2

Place the cartridge into the caulking gun, cut the nozzle to produce a 1/4" thick bead and puncture the inner seal. A 1/4" (0.64cm) bead will cover approximately 27 lineal feet (8.2 meters) per 9 fl oz tube.




STEP 3

Once all of the panels have been properly sized and trimmed, begin applying the adhesive to the **BACK SIDE (ONLY)** of each panel. Use only Loctite Power-grab Heavy Duty Construction Adhesive or Pattex PL200 and follow suppliers instructions.

First apply a bead around the entire perimeter of the **BACK** of the panel. Place the bead to be no more than 1" in from the perimeter at any point.

Next, apply a zig zag or diagonal pattern of additional adhesive across the central sections of the panel, within the perimeter bead. See the images on the right for guidance.





ZINTRA EMBOSSED WALL PANELS

ADHESIVE FIX

INSTALLATION INSTRUCTIONS


STEP 4

Apply the panel to the substrate within 20 minutes and monitor your adhesive to prevent it from skinning over. Set the panels into place and smooth with open palms.


Now, remove the panel from the substrate and hold it off the surface for one minute. Then reset the panel into place and smooth with firm pressure to set it. Use mechanical fasteners if you see the need to help this stay positioned while the adhesive remains wet.

Never use solvent based contact adhesives or any unauthorized adhesives.

Do not reverse or flip panels.



1



2



ZINTRA EMBOSSED WALL PANELS

ADHESIVE FIX

INSTALLATION INSTRUCTIONS


STEP 5

If you have wall GPO's, windows and doors in the way of your panels. Ensure you do not install the panels until you have measured the protruding objects.



Cut with Knife OR jigsaw with BOSCH T313AW3

1



2

Note:
Dry fit after cutting,
to ensure panels fits.

Continuously go over
outline to create clean
and tidy cut.


ZINTRA EMBOSSED WALL PANELS

ADHESIVE FIX

INSTALLATION INSTRUCTIONS

OPTION 1

Install the first panel within the centre of the wall and then install one panel on each side. This means you will have to trim both panel 4 & 5. This ensures the line of sight is directly in the middle of the wall.



OPTION 2

Install the first panel on either the left or right side and work your way across. This means you only have to trim one panel.

