



PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


8in CORNER BEAM - x16



8in BEAM CONNECTOR - x16



BEAMS CLIP - x32




STEP 1

BEAMS ASSEMBLY

ASSEMBLE INDIVIDUALS PARTS AS PER PURCHASED PACKAGE.


FOLD 8IN CORNER BEAM AND SECURE IT BY INSERTING BEAMS CLIPS INTO PRE-CUT RECTANGULAR HOLES.



*BEAMS CLIPS QTY FOR 8IN CORNER BEAM - x2

*IMPORTANT: DO NOT INSERT CLIPS INTO FIRST AND LAST HOLES OF THE BEAM

FOLD 8IN BEAM CONNECTOR AND SECURE IT BY INSERTING INTO PRE-CUT RECTANGULAR HOLES.



STEP 2


8IN BEAMS CONNECTOR INSTALL

2.1 INSERT 8IN BEAMS CONNECTORS INTO ONE END OF 8IN CORNER BEAMS AS SHOWN.

2.2 WITH THE HELP OF FINGER RISE THE TOP OF 8IN CORNER BEAM FOR EASY INSERT.

2.3 INSERT THE 8IN BEAMS CONNECTOR INTO THE CORRESPONDING PRE-CUT RECTANGULAR HOLES IN THE 8IN CORNER BEAM.

2.4 REPEAT STEPS 2.1 - 2.3 FOR EACH 8IN BEAMS CONNECTOR UNTIL THE ASSEMBLY AS SHOWN HAS BEEN COMPLETED.



STEP 3

8IN CORNER BEAMS INSTALL - FINISING INSTALL

3.1 JOINT TWO CORNER BEAMS TOGETHER. USE 2.2 AND 2.3 STEPS FOR CORNER BEAMS INSTALL.

3.2 INSTALL SET OF TWO CORNER BEAMS INTO THE ENDS OF OTHER CORNER BEAM SET AS SHOWN.

3.3 USE STEPS 3.1 - 3.2 FOR EACH SQUARE BEAM INSTALL UNTIL THE ASSEMBLY AS SHOWN HAS BEEN COMPLETED.

