





# ZINTRA STICKS

DOUBLE SIDED PORTRAIT - NARROW & WIDE  
ASSEMBLY INSTALLATION INSTRUCTIONS



# ZINTRA STICKS

## DOUBLE SIDED PORTRAIT - NARROW & WIDE

### ASSEMBLY INSTALLATION INSTRUCTIONS

## PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


ZINTRA STICKS - (16) WIDE OR (36) NARROW




(2) ZINTRA END STICKS




(2) VERTICAL ALUMINIUM TUBE




(6) HORIZONTAL ALUMINIUM TUBE




(4) ACRYLIC COMB



(4) LEVELING FEET SET




(12) COUNTERSUNK BOLTS



## YOU WILL NEED

FOR A TYPICAL ASSEMBLY


SPIRIT LEVEL




TYPE MEASURE



SET OF ALLEN KEYS



DROP SAW WITH SUITABLE BLADE FOR ALUMINIUM CUTTING



# ZINTRA STICKS

## DOUBLE SIDED PORTRAIT - NARROW & WIDE

### ASSEMBLY INSTALLATION INSTRUCTIONS

#### STEP 1



MEASURE THE HEIGHT [X] OF THE INSTALL.  
FOR SAFE AND SECURE INSTALL X CAN NOT EXCEED 2921mm [115"]

IF NEEDED CUT THE VERTICAL ALUMINIUM TUBE TO SUIT

OPTIMAL Y DISTANCE IS  $Y = X - 76\text{mm}$  [3"]




THE MAXIMUM CUT FROM EACH ALUMINIUM TUBE END IS 30mm [1.2"]



#### STEP 2

LEVELING FEET SET INSTALL




# ZINTRA STICKS

## DOUBLE SIDED PORTRAIT - NARROW & WIDE

### ASSEMBLY INSTALLATION INSTRUCTIONS

#### STEP 3


##### FRAME ASSEMBLY




#### STEP 4

##### STICKS INSTALL

ZINTRA STICKS - (8) WIDE OR (18) NARROW



##### FOLD ZINTRA STICKS



# ZINTRA STICKS

## DOUBLE SIDED PORTRAIT - NARROW & WIDE

### ASSEMBLY INSTALLATION INSTRUCTIONS

#### STEP 5



##### END STICKS INTALL

ZINTRA END STICKS - (2) WIDE OR (2) NARROW




5.1 ROTATE PREVIOUS INTALL UPSIDE DOWN



5.2 INSTALL END STICKS - KEEP END STICKS OPEN FOR FURHER INSTALL



#### STEP 6

##### ACRYLIC COMB INSTALL

x4 



# ZINTRA STICKS

## DOUBLE SIDED PORTRAIT - NARROW & WIDE

### ASSEMBLY INSTALLATION INSTRUCTIONS


#### STEP 7

##### STICKS INTALL


ZINTRA STICKS - (8) WIDE OR (18) NARROW



##### 7.1 LOCK END STICKS




##### 7.2 FOLD STICKS AND INSTALL



#### STEP 8

##### FINAL INSTALL

##### 8.1 ROTATE ASSEMBLY TO VERTICAL POSITION



##### 8.2 USING SPIRIT LEVEL AND ADJUSTING LEVEL FEETS FINISH THE INSTALL

