



ZINTRA CLOUDS

TURBINE

INSTALLATION INSTRUCTIONS



BOTTOM PERSPECTIVE



TOP PERSPECTIVE

ZINTRA CLOUDS


TURBINE

INSTALLATION INSTRUCTIONS

PARTS AND HARDWARE

ZINTRA CLOUDS - TURBINE

PARTS WILL COME FLAT PACKED WITH A TOTAL OF 30 PARTS



TOTAL PIECES: 30

P01: 4

P02: 26


(1) 1/4" - 20 HANGER BOLT (FOR USE WITH WOOD SUBSTRATE ONLY)



(1) ADJUSTABLE FASTENER




(1) CABLE WITH SWAGE END, AND BARREL




YOU WILL NEED


SPIRIT LEVEL



DRILL



TAPE MEASURE



ZINTRA CLOUDS

TURBINE

INSTALLATION INSTRUCTIONS


STEP 1

CHECK TO SEE IF PACKAGE CONTAINS ALL COMPONENTS. EVERY PART WILL COME WITH A NUMBER (FROM 1-2) TO REPRESENT THE CLOUD NUMBER.

THERE WILL BE A TOTAL OF 30 CLOUD PARTS:

P01: 4
P02: 26


AND (1) OF EACH: HANGER BOLT, ADJUSTABLE FASTENER, CABLE WITH SWAGE END AND BARREL.



STEP 2

CONNECT P01 TOGETHER VIA THE 2 DOVE TAIL JOINTS (LOCATED ON OPPOSITE ENDS TO EACH OTHER).


NOTE: MAKE SURE THE TOP PANEL HAS THE 4 HOLES ON IT



STEP 3

CONNECT P02 PANEL TO P01 THROUGH THE SLOT THAT DOVE TAIL JOINT CREATES (SHOWN IN B).

MAKE SURE THE CLOUD PIECE IS COVERING THE DOVE TAIL JOINT



ZINTRA CLOUDS


TURBINE

INSTALLATION INSTRUCTIONS

STEP 4


REPEAT STEP 2 AND STEP 3
TO CREATE THE FOUNDATION
FOR THE TURBINE ASSEMBLY.

ALL DOVETAIL JOINTS AND
SUPPORT CLOUDS (P01) SHOULD
BE ASSEMBLED AT THIS POINT



STEP 5


CONTINUE TO FILL ALL THE SLOTS WITH
P02 TO CREATE THE STRUCTURE SHOWN



STEP 6

LOCATE THE MIDPOINT FOR WHERE
THE 4-WAY A.S.K WILL BE LOCATED.

DIMENSIONS OF WHERE THE MIDPOINT
IS SHOWN IN THE DIAGRAM.




ZINTRA CLOUDS

TURBINE

INSTALLATION INSTRUCTIONS

STEP 7

AFTER IDENTIFYING EACH CORRESPONDING POINT ON THE CEILING SUBSTRATE, TO THE POINTS MARKED ON STEP 7, DRILL AND ATTACH 1/4"-20 DOUBLE SIDED HANGER BOLT TO SUBSTRATE. REFERENCE DETAIL (SUPPLIED FOR WOOD ANCHORING ONLY). FOR ALL OTHER SUBSTRATES, STUDS/ ANCHORS MUST BE SOURCED BY THE INSTALLER.




STEP 8

A. IDENTIFY THE THREADED END OF THE BARREL AND THE SWAGE END OF THE WIRE.

B. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH THE LARGE THREADED END OF THE BARREL UNTIL THE SWAGE END IS SEATED IN THE BARREL.


C. ATTACH THE THREADED END OF THE BARREL TO 1 / 4"-20 HANGER BOLT.



STEP 9

LOOP THE WIRE THROUGH THE 4 HOLES ON THE TOP OF P01.

MAKE SURE THE WIRES MEET AT THE MIDPOINT




ZINTRA CLOUDS TURBINE INSTALLATION INSTRUCTIONS

STEP 10

A. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH ONE SIDE OF THE ADJUSTABLE FASTENERS.

B. LOOP THE WIRE AROUND THE CROSSRUNNER WHERE MARKED.

C. RE-INSERT THE PLAIN END OF THE WIRE INTO THE REMAINING SIDE OF THE ADJUSTABLE FASTENER UNTIL SECURE.



STEP 11

ONCE THE HANGING KIT IS PROPERLY SUSPENDED, TRIM THE EXCESS WIRE (IF NECESSARY) WITH WIRE CUTTERS.

NOTE: WIRE IS INFINITELY ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.

