


LONDON PARK gazebo 10' x 10' B101072- (2023)

Assembly instructions



F. Corriveau
INTERNATIONAL

IMPORTANT:

Please read and follow all safety statements, warnings, assembly instructions, use & care directions before attempting to assemble. Each of the recommendations must be followed to ensure the utmost solidity.

Security Rules

Warning:

Keep flame and heat sources away from the gazebo fabric. The fabric may burn if it is exposed to prolonged contact with a source of heat. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.

Regulation

It is the responsibility of the consumer being in accordance with city regulation, construction code, zoning or any limitations and obtaining permit prior assembling gazebo.

Recommendation

- When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to parts.
- Do not use the gazebo during extreme weather conditions.
- Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
- Some parts may contain sharp edges. Use of protective gloves is always recommended.
- When installing and assembling your gazebo, it is recommended that 2 or more adults are involved.
- Considering at least five hours to complete installation, even well anchored, a gazebo unit that is not finished assembly can get or create damages to nearby environment.
- Verify that all nuts and bolts are tightly secured before and during use.
- Use proper tools and equipment for a safe and compliant installation. Never climb, sit or stand on structure while assembling.
- Even if this gazebo is built for all year round, the snow must be removed from the roof at all time.
- Mosquito net and curtains (optional) must be removed from the unit in freezing period.
- Anchoring bolts or other anchoring devices are not supplied.
- Keep away from any electric installation or transportation device.
- Always recommended to keep assembly manual for further reference.

Care

Avoid using a pressure washer. The use of a mild soap with warm water is the best solution for the frame only. A clear water rinse is necessary then. Never use soap on fabric, this will reduce their durability, consequently their lifespan and general look. The use of a soft brush and warm water are an excellent solution for cleaning the fabric.

Warranty

Covered

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for one year.

Not covered

This warranty does not cover commercial use, improper care, neglected storage, vandalism, chemical, acts of nature, fire, oxidation, stains, freeze damage, improper packaging for return and unreasonable or abusive use. Normal discoloration and build-up snow are not covered either.


Customer service:

Consumer












For each part request, please contact your retailer with a description of the problem, pictures and consumer invoice copy, to ensure the proper information to be proceed.












Seller










In addition to all the information already provided by the consumer, any parts requested must mention the person responsible for the client's file, the retailer name, address, branch if applicable, e-mail address, fax and phone number.













PARTS LIST:

No.	Description	Sketch	Qty
A	Post		4
B	Base flange		4
C	Crossbar		4
D	Crossbar		4
E	Connector		4
F	Right brace		4
G	Left brace		4
H	Roof connector		1
I	Roof corner tube		4
J	Corner connector		12
K	Middle connector		1

No.	Description	Sketch	Qty
L	Air vent roof tube		4
M	Air vent support tube		4
N	Roof profile		4
O	Middle support tube		4
P	Roof cap		1
Q	Hook		1
R	Air vent panel		4
S	Air vent panel		4
T	Air vent profile		4
U	Corner connector		8
V	Roof support tube		4



No.	Description	Sketch	Qty
W	Roof support tube		4
X	Left roof panel		4
Y	Middle roof panel		4
Z	Middle roof panel		4
AB	Right roof panel		4
AC	Eave profile		4
AD	Eave profile		4
AE	Air vent mosquito net		1
AF	Mosquito net		1

Hardware Kit:

No.	Description	Sketch	Qty
AA	Bolt M6 X 15mm		152
BB	Bolt M6 X 20mm		17
CC	Bolt M6 X 30mm		8
DD	Bolt M6 X 50mm		4
EE	Half-thread screw M6 X 30mm		24
FF	Nut M6		16
GG	Plastic cap		24
HH	Plastic washer		41
II	Allen key		2
JJ	Spanner		1




A  x 4

B  x 4





Step 1:

Secure base flange (B) to the bottom of post (A) by using bolts (AA). Repeat the step for the rest of the posts. Bolts can be tighten completely.



Step 2:

Insert the connector (E) into a crossbar (C) and a crossbar (D) as figure shown, and secure with bolts (AA). Bolts can be tighten completely.




Step 3:



1. Secure crossbars sets (C & D) on two posts (A) by using half-thread screws (EE). Do not tighten the bolts completely yet. Repeat this step and joint these two assembly with the remaining crossbars (C) and (D).

2. Install plastic caps (GG) as fig.1 shown.


Note: Please check above fig. carefully and make sure all the parts are in right position. For your security, you may need 4 people for this step.

F  x 4

G  x 4









This is important to get square angles in crossbars corners so diagonal measurements (X) should be taken at top of posts in corners and get the same for both. This care refer to get an easy assembly.



Step 4:

Secure left and right braces (G & F) to posts (A) by using bolts (AA) as fig.1 shown. Do not tighten the bolts yet. Then secure other end of braces (G & F) to short and long assembly crossbars (D & C) by using bolts (AA) as fig. 1. Prior final tightening, ensure assembly is fully aligned. Then tighten all loose bolts.



Step 5:

1. Secure roof corner tubes (I) to roof connector (H) using bolts (AA) as shown in fig. 1. Do not tighten the bolts completely yet. Lay down the roof corner tubes (I) on crossbars four corners and secure by using bolts (DD) as shown in fig.2. Tighten corner bolts but not fully.

2. Secure an air vent roof tube (L) to a roof corner tube (I) using bolts (CC) as shown in fig.3. Do not overtighten the bolts yet.

3. Secure middle connector (K) to air vent roof tube (L) by using bolts (AA) as shown in fig.4.

J



x 12

M



x 4

N









x 4

O



x 4



Step 6:


1. Secure corner connectors (J) on the roof corner tubes (I) and air vent roof tubes (L) by using bolts (AA) as shown in fig. 1. Align the parts in position as fig.1 shown. Do not tighten bolts completely yet.
2. Secure air vent support tubes (M) on the corner connectors (J) by using bolts (AA) align the parts in position as fig. 2 shown. Do not tighten the bolts completely yet.
3. Secure roof profiles (N) on the corner connectors (J) by using bolts (AA) align the parts in position as fig. 3 shown. Do not tighten the bolts completely yet.
4. Secure middle support tubes (O) on the roof profiles (N) by using bolts (AA) as fig. 4 shown. Then, secure to the crossbars (D & C) using bolts (AA) as fig.5 shown. Do not tighten the bolts completely yet.

P



x 12

Q



x 4

V








x 1

W



x 4




Step 7:

1. Insert bolts (BB) and washers (HH) through roof cap (P), and secure with middle connector (K) as fig. 1. Tighten bolts.

2. Secure hook (Q) to roof connector (H) as fig. 2 and tighten the hook.


3. Secure roof support tubes (V & W) on the middle support tubes (O) and corner connectors (J) by using bolts (AA). Align the parts in position as fig. 3 & 4 shown. Do not tighten bolts completely yet.

R



x 4

S



x 4

T





x 4

U



x 4

**Step 8:**



1. Lay down air vent panels (R & S) on middle of the roof under the roof cap (P), and insert air vent roof tubes (L) groove. Note the air vent panels (R & S) need to overlap. Use bolts (AA) and plastic washers (HH) to secure with air vent support tube (M) as fig. 1 & 2 shown. Then insert air vent profiles (T) at the end as fig. 3 shown and secure with bolts (BB) & plastic washer (HH) & nuts (FF). Do not tighten the bolts completely yet.

2. Finally insert bolts (AA) through corner connectors (U), secure with air vent roof tubes (L) as fig. 4 shown. Do not tighten the bolts completely yet.

Repeat the steps 1 & 2 for remaining 3 sides of roof panels. Bolts can be tighten completely.

Notes: Install clockwise to prevent the panels slide off.

X		x 4	Y		x 4
Z		x 4	AB		x 4
AC		x 4	AD		x 4
U		x 4			



Step 9:


1. Lay down middle roof panels (Y & Z) on middle support tubes (O) and under the roof profile (N) & corner tubes (I) groove. Note the middle roof panels (Y & Z) need to overlap. Use bolts (AA) and plastic washers (HH) to secure with roof support tubes (V & W) as fig. 1 & 3 shown. Do not tighten the bolts completely yet.

2. Then insert left & right roof panels (X & AB) into roof corner tubes (I) groove. Note the middle roof panels (Y & Z) need to overlap. Use bolts (AA) and plastic washers (HH) to secure with roof support tubes (V & W) as fig. 2 & 3 shown. Do not tighten the bolts completely yet.

3. Finally insert eave profiles (AC & AD) at the end as fig. 4 shown and secure with bolts (BB) & plastic washers (HH) & nuts (FF). Do not tighten the bolts completely yet. Repeat the steps 1 to 3 for remaining 3 sides of roof panels. Bolts can be tighten completely.


Notes: Install clockwise to prevent the panels slide off.

AE






x 1

AF



x 1



Step 10:

1.Place air vent mosquito net (AE) on the roof profiles (N) by fitting velcro male and female properly as fig.1 shown.

2.Hang the mosquito net (AF) by hooks properly.

3.Depend of patio surface, use proper anchoring devices. Anchors are not supplied.

4.Remove all gazebo assembly stickers.

5.Final tightening of all remaining untighten bolts.

Please ensure posts and ground are perpendicular wick each other once the unit is assembled. Enjoy your leisure time with the gazebo.