



Stormtite®


SYNTHETIC ROOF UNDERLAYMENT

Application Instructions

ENGLISH

IMPORTANT MESSAGE • PLEASE READ! Stormtite sythetic underlayment with an advanced membrane structure comes printed with installation lines, making application easy. It is an impervious, high tear strength underlayment that is ideal for secondary water shedding beneath shingled roofs. It is incredibly flexible and therefore easily installed around vent stacks, dormers, chimneys and other roof-top structures.

STEPS 1-3



STEP 1:

PREPARE THE ROOF DECK: The roof deck must be swept clean and be smooth and dry before installation starts.


STEP 2:

Stormtite should be unrolled and laid flat to the roof deck, horizontally (parallel to eave), starting at the bottom of the roof (overlapping the eave protection by at least 4") with the printed side up.

STEP 3:

There should be minimum, 4-inch side laps and 6-inch end laps.

STEPS 4-5



STEP 4:

Attach Stormtite to the roof with roofing nails or staples having one inch diameter plastic/metal caps. Fasten with enough fasteners to safely hold the underlayment in place until shingle application. Additional fastening should be considered if shingle application will not take place soon thereafter. Typically fasteners should be spaced at approximately 8-inch on center on both side and end laps in normal wind zones.

In high wind zones or coastal areas, fastening spacing may need to be doubled to 4-inches on center; check local building codes.

STEP 5:

In all cases, fasten at approximately 24-inches on center down the middle of the roll in the field of the roof.

IMPORTANT

Stormtite synthetic underlayment is a vapor retarder, so the airspace beneath the roof deck should be properly and thoroughly ventilated to avoid risk of moisture condensation.