




# Record Storage Stand CF1123



### PARTS LIST





#### HARDWARE LIST

#1	#2	#3	#4 <b>(a) Trimina</b>	#5
1/4"*45mm	1/4"*10mm	1/4"*13mm	7*38mm	
Bolt 8 PCS (Extra 1)	Spring Washer 8 PCS (Extra 1)	Flat Washer 8 PCS (Extra 1)	Screw 10 PCS (Extra 1)	Cam Bolt 20 PCS (Extra 1)
#6	#7 8*30mm	#8 M4	#9	#10
Cam Lock 20 PCS (Extra 1)	Wood Dowel 34 PCS (Extra 1)	Allen Wrench 1 PC	Cam Sticker 20 PCS (Extra 1)	Safety Strap Kit 1 SET


## ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach legs (part K2) to bottom panel (part E2) using bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #8).



Step 2. Screw cam bolts (part #5) into panels (parts A2, G2 & I2) using phillips head screwdriver.


Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.



x 6


Step 3. Screw cam bolts (part #5) into panels (parts B2, C2, D2 & H2) using phillips head screwdriver.

Note: Do not over tighten cam bolts. Stop tightening once threads on cam




Step 4. Attach partition panels (part I2) to fixed shelf (part F2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 5. Attach fixed shelves (part F2) to partition panels (part I2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 6. Attach panels (parts A2 & G2) to fixed shelves (part F2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.




Step 7. Attach assembled unit (parts A2, G2 & I2) to left panel (part C2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 8. Attach panels (parts B2 & H2) to lower partition panel (part J2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 9. Attach assembled unit (parts B2 & H2) to left panel (part C2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.

Note: Cam locks must rotate a full 180°. See pictured insert.




Step 10. Attach right panel (part D2) to assembled unit (parts A2, B2, G2, H2 & I2) using cam locks (part #6), wood dowels (part #7) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.




Step 11. Attach bottom panel (part E2) to assembled unit (parts B2, C2, D2, H2 & J2) using screws (part #4), wood dowels (part #7) and allen wrench (part #8).



Step 12. Carefully turn unit upright. Using cam stickers (part #9) cover all cam locks (part #6).







#9 x 20

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #10) must be installed to prevent tipping damage

and/or injury.





#10	Α	В	С	D	Е
		0		Manage .	
			8*3*15mm	8*4*35mm	
Safety Strap Kit	Wall Anchor	Bracket	Short Screw	Long Screw	Safety Wall Strap
1 SET	1 PC	2 PCS	1 PC	1 PC	1 PC

#### SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

- 1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to upper back panel (part G2) using phillips head screwdriver.
- 2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in upper back panel (part G2) where bracket (B) is attached. Tap wall anchor (A) into the hole.
- 3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

  Note: This item is not intended for clothing storage use.

