


















CROSLEY

FURNITURE






















Hall Tree
CF6030



PARTS LIST


<p>A2</p> 	<p>B2</p> 	<p>C2</p> 	<p>D2</p> 	<p>E2</p> 
<p>Top Panel 1 PC</p>	<p>Left Brace 1 PC</p>	<p>Right Brace 1 PC</p>	<p>Upper Fixed Panel 1 PC</p>	<p>Back Cross Bar 1 PC</p>
<p>F2</p> 	<p>G2</p> 	<p>H2</p> 	<p>I3</p> 	<p>J2</p> 
<p>Seat Panel 1 PC</p>	<p>Upper Partition Panel 1 PC</p>	<p>Back Middle Brace 1 PC</p>	<p>Lower Partition 1 PC</p>	<p>Left Panel 1 PC</p>
<p>K2</p> 	<p>L2</p> 	<p>M2</p> 	<p>N2</p> 	<p>O3</p> 
<p>Right Panel 1 PC</p>	<p>Bottom Panel 1 PC</p>	<p>Top Back Panel 1 PC</p>	<p>Middle Back Panel 2 PCS</p>	<p>Bottom Back Panel 1 PC</p>
<p>P2</p> 				
<p>Door 1 PC</p>				

HARDWARE LIST

#1 	#2 	#3  5*3*12mm	#4 	#5  5/32*6mm
Wood Dowel 30 PCS (Extra 1)	Hook 3 PCS	Bronze Screw 6 PCS (Extra 1)	Handle 2 PCS	Round Head Bolt 4 PCS (Extra 1)
#6 	#7 	#8 	#9  6*3*15mm	#10  1/4*50mm
Cam Bolt 14 PCS (Extra 1)	Cam Lock 14 PCS (Extra 1)	Magnet 1 PC	Round Head Screw 2 PCS (Extra 1)	Bolt 6 PCS (Extra 1)
#11 	#12  7*38mm	#13 	#14 	#15 
Barrel Nut 6 PCS (Extra 1)	Tapping Bolt 8 PCS (Extra 1)	Spring Hinge 2 PCS	Left Hinge 1 PC	Right Hinge 1 PC
#16  5*3*12mm	#17  5*3*15mm	#18  8*3*15mm	#19 	#20 
Short Screw 6 PCS (Extra 1)	Long Screw 8 PCS (Extra 1)	Screw 48 PCS (Extra 1)	Cam Sticker 14 PCS (Extra 1)	Allen Wrench 1 PC
#21 				
Safety Strap Kit 1 SET				

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach hinges (parts #14 & #15) to door (part P2) using short screws (part #16) and phillips head screwdriver. Attach handles (part #4) to door (part P2) using round head bolts (part #5) and phillips head screwdriver. Attached hooks (part #2) to back cross bar (part E2) using bronze screws (part #3) and phillips head screwdriver.





Step 2. Attach magnet (part #8) to seat panel (part F2) using round head screws (part #9) and phillips head screwdriver. Attach cam bolts (part #6) into pre-drilled holes of panels (parts B2, C2 & F2) using phillips head screwdriver.



Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.



Step 3. Attach upper fixed panel (part D2) to right brace (part C2) using wood dowel (part #1), cam locks (part #7) and phillips head screwdriver.



Note: Cam locks must rotate a full 180°. See pictured insert.





- #1  x 1
- #7  x 2

Step 4. Attach back cross bar (part E2) to right brace (part C2) using wood dowel (part #1), cam locks (part #7) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.




- #1  x 1
- #7  x 2

Step 5. Attach left brace (part B2) to assembled unit (parts D2 & E2) using wood dowels (part #1), cam locks (part #7) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.



Step 6. Attach top panel (part A2) and upper partition panel (part G2) to assembled unit (parts B2, C2 & D2) using wood dowels (part #1), tapping bolts (part #12) and allen wrench (part #20).




Step 7. Attach seat panel (part F2) and back middle brace (part H2) to assembled unit (parts B2, C2 & E2) using wood dowels (part #1), tapping bolts (part #12) and allen wrench (part #20).




Step 8. Attach panels (parts I3, J2 & K2) to seat panel (part F2) using wood dowels (part #1), cam locks (part #7) and phillips head screwdriver.


Note: Cam locks must rotate a full 180°. See pictured insert.




Step 9. Attach door (part P2) by placing hinges in the pre-drilled holes of panels (parts J2 & K2).




Step 10. Attach bottom panel (part L2) to assembled unit (parts I3, J2 & K2) using wood dowels (part #1), bolts (part #10), barrel nuts (part #11) and allen wrench (part #20).



Step 11. Carefully turn unit upright. Attach back panels (parts M2, N2 & O3) to assembled unit (parts A2, B2, C2, E2, F2, H2, J2, K2 & L2) using screws (part #18) and phillips head screwdriver.



Step 12. Attach spring hinges (part #13) to panels (parts J2 & K2) and door (part P2) using long screws (part #17) and phillips head screwdriver.










- | | | |
|-----|---|-----|
| #13 |  | x 2 |
| #17 |  | x 8 |

Step 13. Using cam stickers (part #19) cover all cam locks (part #7).

Important: Safety strap kit (part #21) must be installed to prevent tipping damage and/or injury.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.




#21	A	B	C	D	E
			 8*3*15mm	 8*4*35mm	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to top panel (part A2) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A2) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



This is a permanent label.
Do not remove!