




CROSSROADS SHELF


ASSEMBLY INSTRUCTIONS

CROSSROADS SHELF Recommended Tools




Drill with 7/32" Allen Driver Bit

OR




7/32" Allen Wrench




9/16" Socket Wrench

OR




9/16" Combination Wrench



Bubble Level

**USE TEAMWORK - WE RECOMMEND
TWO PEOPLE FOR THIS BUILD.**

CROSSROADS SHELF Parts



PARTS	QTY
A. Top and Bottom Shelf Frame (fixed)	1
B. Adjustable Shelf Frames	3
C. Top Shelf (Wood)	1
D. Adjustable and Bottom Shelf (Wood)	4
E. Legs	4
F. X-Brace	2
G. Hex Socket Button Head Cap Screws	24
H. Nylock Nuts	24
I. #8 Phillips Pan Head Screws	20

CROSSROADS SHELF Assembly Instructions




Figure 1

1. Lay the wood shelf (D) on a flat, stable surface.

2. Position the shelf frame (A or B) on top of the wood, ensuring the edge of the wood and the edge of the frame are even on all sides (figure 1).

3. Attach the shelf frame to the shelf wood using four #8 pan head screws (I) (provided).

NOTE:

The top shelf (C) is a little larger than the other wood pieces and will hang over the (A) frame. This should only be installed on one of the (A) shelf frames.




Figure 2

4. Lay one left and one right leg (E) on a flat, stable surface. The holes in the legs will face outward. Ensure that the adjustable feet are facing the same direction.

5. Position the bottom shelf (A & D) between the two legs, aligning the holes in the shelf with the holes in the legs (Figure 2).

CROSSROADS SHELF Assembly Instructions




Figure 3

NOTE:

Make sure you have the bottom shelf. It will look like the adjustable shelves except for two additional screw holes on the back plane.

6. Insert one button head cap screw (G) in each hole fastening with one nylock nut per screw (H). Do not tighten (Figure 3).




Figure 4

7. Place the remaining two legs (E) on the front of the shelf ensuring the holes in both shelf and legs are aligned. Install screws and nuts on the remaining two legs. Do not tighten (Figure 4).




Figure 5

8. Stand the shelf unit upright and install the remaining shelves, ending with the top shelf (Figure 5).

NOTE:

The top shelf will look slightly different from the other shelves. Like the bottom shelf, it will have two additional holes on the back plane. The wood top is also a little larger than the steel shelf frame. This will rest on the top of the legs. Ensure top and bottom shelf back plane holes face the same direction.




Figure 6

9. Place the x-brace pieces (F) on a flat, stable surface aligning the center hole of each. Join with one button head cap screw (G) and one nylock nut (H). When tightening, ensure the x-brace can still be adjusted to fit the shelf unit. (Figure 6).




Figure 7

10. Attach the x-brace to the back of the shelf unit using the remaining four button head cap screws (F) and four remaining nylock nuts (G) (Figure 7).

11. Tighten all hardware, using a level to ensure the shelving unit is square. Once the unit has been installed, adjust the feet using the level to ensure the shelves are level.

WE LOVE WHAT YOU ARE DOING WITH THE PLACE

**CONGRATULATIONS ON YOUR DECISION TO BRING HOME
AN AMERICAN MADE PRODUCT OF THE HIGHEST QUALITY.
WE HOPE YOUR CROSSROADS SHELF BRINGS ART AND FUNCTION
INTO YOUR LIFE.**

**DESIGNED AND CRAFTED
ENTIRELY IN THE**

U.S.A.



IronwoodHardware.com