

Linspire

page: 1






Installation diagram

Product
name

TDY96-A

Product
specifications

670*900*900mm

Hardware list				Component list			
Component number	Component name	Explanatory chart	No.of component	Component number	Component name	No.of component	Component material
A	Long Bolts	 M6*50	2	①	Seat Back	1	Teddy frabic+wood frame+foam+polypropylene fiber
B	Short Bolts	 M6*25	10	②	Seat Bottom	1	Teddy frabic+wood frame+foam+polypropylene fiber
C	Small Washers		10	③	Left Wooden leg	1	rubber wood
D	Large Washers		2	④	Right Wooden Leg	1	rubber wood
E	Allen wrench		1	⑤	Post Metal Frame	1	metal
				⑥	Front Metal Frame	1	metal




design sketch


Installation Tool



Installation Personnel




step 1




step 2

Leg and body installation method


STEP 1 Line up the plugs of the Seat Back(①)with the holes on the armrests of Seat Bottom(②).



STEP 2 Align the Seat Back(①)with two arms, and insert the Seat Back(①) to the Seat Bottom(②)




STEP 3 Make sure the back and the bottom tight fit, then drew the screws in, then tighten.



D  2 PCS

A  2 PCS

STEP 4 Don't tighten all the screws.



B  6 PCS

C  6 PCS

Linspire

page: 2

Installation diagram






Product
name

TDY96-A

Product
specifications

670*900*900mm

Hardware list

Component number	Component name	Explanatory chart	No.of component
A	Long Bolts	 M6*50	2
B	Short Bolts	 M6*25	10
C	Small Washers		10
D	Large Washers		2
E	Allen wrench		1

Component list

Component number	Component name	No.of component	Component material
①	Seat Back	1	Teddy frabic+wood frame+foam+polypropylene fiber
②	Seat Bottom	1	Teddy frabic+wood frame+foam+polypropylene fiber
③	Left Wooden leg	1	rubber wood
④	Right Wooden Leg	1	rubber wood
⑤	Post Metal Frame	1	metal
⑥	Front Metal Frame	1	metal




design sketch


Installation Tool



Installation Personnel




step 1



step 2

Leg and body installation method

STEP 5 Make sure the longer side of ③ and ④ is facing theback of the chair.Then tighten all the screws.



STEP 6 After assembly, please check that all screws are tight.

