

## ACCESSORY RAIL FILLER

### Tools Required

- Cordless driver with magnetic post and following tips
  - #2 Phillips Drive

### Hardware Required (Included)

Quantity varies by model

- 2—Panhead Phillip Sheet Metal Screws #8 X 5/8"
- 12—Panhead Phillips Wood Screw #8 x 5/8"

### Installation

1. Unpack Filler and hardware.
2. Determine if Filler is used at the end or in the middle of a configuration as seen in Figure A. If used on the end, only 1 Mounting Bracket will be used. If centered above the Mid Support Leg, Both Brackets will be used.
3. During installation, ensure to leave enough space (1 3/16") to allow for Filler to fit between surfaces.
4. After Worksurface installation, place the Filler between the surfaces at the desired location. Attach the Filler to the Mounting Brackets with the sheet metal screw as shown in Figure B. If attaching the filler to the leg in an end of run application, attach the filler to the leg using the supplied sheet metal screw.
5. Attach the Worksurface brackets to the underside of the Top using the #8 -5/8" Wood Screws.

Figure A




Figure B

