

CADDY Sway Bracing Cable Swaging Tools and Cutters

For instruction on how to use your swaging tool or cutter, read through the manufacturers instruction that are enclosed with this sheet.



CSB3346SB
402209



CSBC9, CSBC1218, CSBC48,
402211, 402535, 402536



CSB12SBHS
404461



CSB48
402212

Part Number	Article Number	VST Part Number	Description	Cable Color, Brace Size and Cable Diameter that the tool or cutter can be used with			
				Red, #12 3/32 in [2.4mm]	White, #18 1/8 in [3.2mm]	Blue, #36 3/16 in [4.8mm]	Yellow, #48 1/4 in [6.4mm]
CSB3346SB	402209	1-SBHS	3 cavity hand swaging tool	X	X	X	
CSB12SBHS	404461	12-SBHS	Single cavity hand swaging tool	X			
CSBBS121836	402534	1-SBBS	Battery swaging tool	X	X	X	
CSB48	402212	48-SBHS	Single cavity hand swaging tool				X
CSBC1218	402535	C7	Cable cutter	X	X		
CSBC9	402211	C9	Cable cutter	X	X	X	
CSBC48	402536	C12	Cable Cutter	X	X	X	X

Note: For hand swaging tools, 2 swages are required for #12 and #18 size cables and 3 swages are required for #36 and #48 size cables.

For battery operated swaging tool, 1 swage is required for #12 and #18 size cables, 2 swages are required for #36 size cable and 3 swages are required for #48 size cable.

WARNING:

- Pentair products shall be installed and used only as indicated in Pentair product instruction sheets and training materials. Instruction sheets are available at www.erico.pentair.com and from your Pentair customer service representative.
- PENTAIR products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.
- All instructions must be completely followed to ensure proper and safe installation and performance.
- Improper installation, misuse, misapplication or other failure to completely follow Pentair's instructions and warnings may cause product malfunction, property damage, serious bodily injury and/or death, and void your warranty.
- Products that are manufactured using spring steel components shall be used only in a non-corrosive indoor environment.
- All pipe supports, hangers, intermediate components and structural attachments must ONLY be used as described herein and are NEVER to be used for any other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:

- Conformance to all governing codes.
- The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer.
- Using appropriate industry standard hardware as noted above.

SAFETY INSTRUCTIONS:

All governing codes and regulations and those required by the job site must be observed.
Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.



Pentair, CADDY, ERICO CADWELD, ERICO CRITEC, ERICO, ERIFLEX, and LENTON are owned by Pentair or its global affiliates. All other trademarks are the property of their respective owners. Pentair reserves the right to change specifications without prior notice.

TECHNICAL SUPPORT:
www.erico.pentair.com

CFS430_F

1 OF 1

© 2010-2018 Pentair All Rights Reserved

