

WHITE SHARK



BT/WIRELESS
DAGONET
GAMING MOUSE

User manual

Wired connection

1. Take out the USB to USB-C cable and connect the mouse to the computer.
2. The computer will automatically recognize and configure the mouse.
3. When the configuration is complete, the mouse is ready for use.
4. The mouse is charged whether the power switch is on or not.
5. The mouse takes about two hours to fully charge.
6. Insert the USB cable to automatically switch the mouse to the cable connection.

EN-1

2.4G Wireless connection

1. Remove the cable from the mouse, flip the mouse power switch down to enter the 2.4G mode.
2. The mouse can be used normally in wireless mode after the 2.4G receiver is connected to the computer device by the USB-C to USB cable.
3. If the mouse cannot be connected to the computer device through the above methods, please press and hold the left, middle, and right buttons for about 3 seconds at the same time until the indicator of the mouse bottom turns green and flashes rapidly.
4. The computer will automatically recognize and configure the mouse when the 2.4G receiver is connected into the computer device.
5. When the configuration is complete, the mouse is ready to use.
6. When the battery is low, the indicator light will blink red light.
7. Charge the mouse when the battery is low.

BT connection

1. Remove the cable from the mouse, flip the mouse power switch up to enter the BT mode.
2. When the left, middle and right buttons are pressed at the same time for about 3 sec, the blue light of the mouse bottom will flash rapidly which means entering the BT pairing mode.
3. Then turn on BT on your computer device and search for BT devices. Connect the corresponding BT device name, the BT connection is successful when the indicator is off.

BT Name: DAGONET

Features:

1. Super lightweight professional gaming mouse only around 50 g.
2. Polling: up to 1 kHz for wired version / 1 kHz for 2.4G version / 125 Hz for BT version.
3. Power Saving: The mouse will enter sleep mode if there is no operation for more than 3 minutes. The mouse will go back to work by any movement on the desk.
4. DPI levels indicator light inside the mouse
Press the DPI Loop button to switch between mouse DPI levels:
800/1600/2400/3200/6400/12000DPI SWITCHABLE

EN-2

Low power indicator:

1. When the battery is low, the indicator of mouse's bottom will flash red.
2. The indicator blue light will be steady on when charging;
3. After charging is completed, the blue light will be turned off.

Troubleshooting:

1. If the mouse does not respond, check whether the USB port cable or receiver is properly plugged in, or try another USB port. Check whether the mouse is BT or 2.4G connected.
2. If the mouse does not work when BT, try turning the mouse and BT on the computer. Repairing can also solve this problem.
3. If the mouse moves slowly, jumps, or is delayed, try another surface. Dark, dirty, uneven, and bright surfaces may affect mouse performance. Mouse pad highly recommended. This also indicates that the mouse is low on battery power and needs to be recharged.

3.0 Supporting System

—Windows 2000/XP/VISTA/7/8/10 & MAC/ BT only support BLE

EN-3

WHITE SHARK



BT/WIRELESS
DAGONET
GAMING MOUSE

Upute

Žičana veza

1. Izvadite USB na USB-C kabel i povežite miš s računalom.
2. Računalo će automatski prepoznati i konfigurirati miš.
3. Kada je konfiguracija dovršena, miš je spreman za korištenje.
4. Miš se puni bez obzira na to je li prekidač za napajanje uključen ili ne.
5. Mišu je potrebno oko dva sata da se potpuno napuni.
6. Umetanjem USB kabela miš automatski prelazi na žičanu vezu.

HR-1

2.4G bežična veza

1. Uklonite kabel iz miša i prebacite prekidač za napajanje prema dolje kako biste ušli u 2.4G način rada.
2. Miš se može normalno koristiti u bežičnom načinu rada nakon što je 2.4G prijemnik povezan s računalom pomoću USB-C na USB kabela.
3. Ako se miš ne može povezati s računalom gore navedenim metodama, pritisnite i držite lijevu, srednju i desnu tipku istovremeno oko 3 sekunde dok indikator na dnu miša ne zasvijetli zeleno i ne počne brzo treperiti.
4. Računalo će automatski prepoznati i konfigurirati miš kada je 2.4G prijemnik povezan s računalom.
5. Kada je konfiguracija dovršena, miš je spreman za korištenje.
6. Kada je baterija slaba, indikator će treperiti crvenim svjetlom.
7. Napunite miš kada je baterija slaba.

BT veza

1. Uklonite kabel iz miša i prebacite prekidač za napajanje prema gore kako biste ušli u BT način rada.
2. Kada pritisnete lijevu, srednju i desnu tipku istovremeno na oko 3 sekunde, plavo svjetlo na dnu miša će brzo treperiti, što označava ulazak u način uparivanja BT.
3. Zatim uključite BT na računalu i potražite BT uređaje. Povežite odgovarajući naziv BT uređaja, a BT veza će biti uspješna kada se indikator ugasi.

BT ime: DAGONET

Značajke:

1. Super lagani profesionalni gaming miš, težine samo oko 50 g.
2. Stopa osvježavanja: do 1 kHz za žičanu verziju / 1 kHz za 2.4G bežičnu verziju / 125 Hz za BT verziju.
3. Ušteda energije: Miš prelazi u način mirovanja ako nema aktivnosti dulje od 3 minute. Miš se aktivira bilo kojim pomakom po površini stola.
4. Indikator razina DPI unutar miša.
5. Pritisnite tipku za promjenu DPI kako biste prelazili između razina: 800/1600/2400/3200/6400/12000 DPI.

HR-2

Indikator slabe baterije:

1. Kada je baterija slaba, indikator na dnu miša treperi crveno.
2. Plavo svjetlo će svijetliti tijekom punjenja.
3. Nakon što je punjenje dovršeno, plavo svjetlo se gasi.

Rješavanje problema:

1. Ako miš ne reagira, provjerite je li USB kabel ili prijemnik pravilno priključen ili pokušajte drugi USB priključak. Provjerite je li miš povezan putem BT ili 2.4G veze.
2. Ako miš ne radi preko BT, pokušajte ponovno uključiti miš i BT na računalu. Ponovno uparivanje također može riješiti problem.
3. Ako se miš kreće sporo, skače ili ima kašnjenje, pokušajte s drugom površinom. Tamne, prljave, neravne ili svijetle površine mogu utjecati na performanse miša. Preporučuje se upotreba podloge za miš. Ovo također može značiti da je baterija pri kraju i da je potrebno punjenje.

Podržani sustavi:

—Windows 2000/XP/VISTA/7/8/10 & MAC/ BT podržava samo BLE

HR-3

WARRANTY CARD / JAMSTVENI LIST

ITEM/MODEL: Naziv/model proizvođača:	
RECEIPT NO. / DATE OF PURCHASE: Broj i datum računa:	
SELLING SPOT (COMPANY): Prodajno mjesto:	
THE CUSTOMER: Kupac:	
WARRANTY PERIOD (MONTHS): Jamstveni rok (Mjeseci):	36 SIGNATURE / STAMP: Potpis i pečat:

All White Shark products are examined and tested after each stage of the production process and have all the required certificates (EMC, CE...). The products are subject to the following warranty conditions: • The warranty period for White Shark products is 36 months (on batteries 6 months) and begins on the day of being sold in the store. • The warranty can only be claimed upon presentation of the original purchase invoice and a filed warranty paper with a stamp from the store it was bought at, and if the product has original packaging and all components and equipment • All malfunctioning of the product resulting from factory defects, that occur during the warranty period, and in the normal use of the product in compliance with all instructions will be removed. This warranty covers only defects in material and production. • If the product malfunctions during the warranty period, your White Shark distributor will give you the product (after which is checked by a professional) repaired or replaced • If the repair at the authorized service center is not completed within 30 days of being received at the service center, we will replace the product with a new one. If the repair during the warranty period lasts longer than 15 days, the warranty period is extended by as many days as the repair lasted. • If the device needs to be repaired within the warranty period, contact the store where you bought the product. If the product has to be sent to an authorized service center or general distributor, please send the product (with all parts and accessories) in the original packaging and with all the necessary documents (invoice, warranty card, etc.). The product can be repaired only in the authorized service center of the importer. The costs of shipping the product to the service center are funded by the customer. Possible damage to the product that can occur during transport is at the expense and risk of the buyer. Sending the product from the service center to the customer is funded by the service technician/the importer. This warranty does NOT cover: • Damage or malfunctions that would occur as a result of incorrect connection, incorrect polarization, incorrect battery placement, etc. • Defects caused by improper handling of products, use of parts or equipment that is not prescribed by our specifications, unauthorized product modification, and defects mechanical damage to the product • Defects that can occur due to product fall, use of force, natural disasters (flood, fire, thunder, earthquake, ...), due to battery leakage, due to unstable 220V voltage, frequent variations and/or power outages, etc. • Damage caused during transport to the customer • Products that have been opened or repaired by an unauthorized person • Parts that are considered consumables such as batteries, etc.

Svi White Shark proizvodi su provjereni i testirani nakon svake faze proizvodnog procesa te imaju sve potrebne certifikate (EMC, CE...) te podliježu sljedećim jamstvenim uvjetima: • Jamstveni rok na White Shark proizvode je 36 mjeseci (na baterije 6 m) i počinje teći danom prodaje u trgovini • Jamstvo se može ostvariti samo uz predočenje originalnog računa o kupnji i uredno popunjenog jamstvenog lista sa žigom trgovine, te ako proizvod ima originalnu ambalažu i sve sastavne dijelove i opremu. • Svi nedostaci i kvarovi koji su posljedica tvorničkih grešaka i koji su nastali u jamstvenom roku i pri normalnoj uporabi proizvoda i pri postavljanju svih naputaka će biti otklonjeni. Ovo jamstvo obuhvaća samo greške nastale u materijalu i izradi. • Ako se proizvod pokvari tijekom jamstvenog roka, Vaš White Shark distributer će Vam proizvod popraviti ili zamijeniti nakon što ga provjeri stručna osoba • Ako popravak u ovlaštenom servisu nije izvršen u roku 30 dana od primitka u servis, proizvod ćemo zamijeniti novim. U slučaju da popravak u jamstvenom roku traje duže od 15 dana, jamstveni rok se produžuje za onoliko dana koliko je popravak trajao. • Ako se ukaže potreba popravka uređaja u jamstvenom roku, kontaktirajte trgovinu u kojoj ste proizvod kupili. Ako proizvod treba poslati ovlaštenom servisu ili generalnom distributeru, molimo Vas da kompletan proizvod (sa svim dijelovima i opremom) bude zapakiran u originalnu ambalažu te da priložite sve potrebne dokumente (račun i ovjereni jamstveni list). Popravak aparata vrši se isključivo u ovlaštenom servisu uvoznika. Troškove prijevoza proizvoda na servis snosi kupac. Kupac preuzima rizik za moguća oštećenja tijekom prijevoza. Slanje proizvoda od servisa do kupca snosi serviser tj. uvoznik. Ovo jamstvo NE obuhvaća: • Oštećenja ili kvarove koji su nastali kao posljedica nepravilnog priključivanja, krive polarizacije, pogrešnog stavljanja baterija i sl. • Kvarove nastale zbog nepropisanog rukovanja proizvodom, korištenja dijelova ili opreme koja nije propisana našim specifikacijama, neovlaštenog modificiranja proizvoda te kvarove nastale mehaničkim oštećenjem proizvoda • Kvarove koji mogu nastati uslijed pada proizvoda, uporabe sile, više sile tj. elementarnih nepogoda (poplava, požar, grom, potres, ...), uslijed curenja baterije, uslijed nestabilnog 220V napona, čestih varijacija i/ili nestanaka struje i sl. • Oštećenja nastala pri prijevozu do kupca • Proizvod koji je otvoren i/ili popravljan od strane neovlaštene osobe • Dijelove koji se smatraju potrošnim kao što su baterije i sl.

WHITE SHARK

HR-4