

TOOLS



**RUBBERMAID PULSE™
MOPPING KIT WITH
SINGLE-SIDED FRAME**



**18" MICROFIBER
DAMP ROOM MOP**
**18" MICROFIBER
SCRUBBER MOP**
**18" MICROFIBER
HIGH ABSORBENCY
MOP**



**RUBBERMAID
PULSE™ CADDY**



**STABLE
SAFETY
SIGN**



**HIGH
SECURITY
CLEANING
CART**

NOTES

- Use High Absorbency Mop to clean larger areas. Replace the pad every time the Rubbermaid PULSE needs to be refilled.
- Use the Scrubber Mop on tile or stone floors.
- Dust mop before damp mopping for optimal infection prevention and floor maintenance.
- Follow all established safety procedures.
- Don all appropriate Personal Protective Equipment (PPE) (glasses, gloves, etc.).



1

FILL
Rubbermaid PULSE Caddy
with cleaning solution.



2

PLACE
Rubbermaid PULSE Caddy
in the Rubbermaid High
Security Cleaning Cart.



3A

PLUG
the Rubbermaid PULSE
Caddy Clean Connect™ hose
into the cap fitting to fill the
reservoir. Cleaning solution
will automatically stop
filling when full. Disconnect
Clean Connect hose when
finished.

NOTE: If air in the Rubbermaid
PULSE reservoir impedes the
flow of liquid, loosen the cap
and perform a manual fill.



3B


**FOR MANUAL
FILLING,**
open the red cap at the top
of the Rubbermaid PULSE
reservoir, fill the reservoir,
and replace the cap.



4

PLACE

Stable Safety Sign to alert pedestrians of the potential slip-and-fall hazard.



8

REMOVE

soiled mop by placing one foot on an exposed edge of the mop and the other foot on the end of the Quick-Connect Frame. Pull the handle upward and the mop will peel away from the Quick-Connect Frame.

NOTE: the soiled mop should be removed from the frame when finished mopping or when mop is dry.



5

AFFIX

the damp mop to the Quick-Connect Frame.



9

LIFT

the soiled mop, using the Quick-Connect Frame, positioned at a 90° angle to the mop.



6

START

in the far corner of the room, pressing the red trigger button on the handle of the Rubbermaid PULSE, dispensing enough cleaning solution onto floor to moisten the damp mop.



10

PULL

the soiled mop from the frame and drop into the Rubbermaid Mesh Laundry Net.



7

MOP,

moving backwards, using Figure 8 strokes. As the mop becomes dry, press the trigger to dispense more cleaning solution.