


## GENERAL NOTES


1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.

## RUNOFF ASSEMBLY HARDWARE



3500009400  
SCR TP-AB 10X1 FT PH



## MODESTY ASSEMBLY HARDWARE (OPTIONAL)




SA922-0005-31S  
BRKT MODESTY PANEL



19917-4194-36  
SCR TP-A 8X5/8 PN PH



WORKSURFACE HAS POCKETS ON  
THE UNDERSIDE THAT THE FRAME  
PLATES WILL SIT IN



## ATTACH OPTIONAL MODESTY PANEL

