


# CREDENTIALS FULL BANK CREDENZA GUNLOCKE ASSEMBLY

AA013-0006-00


## GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.

## CHASSIS ASSEMBLY HARDWARE




11917-4616-35  
BOLT JT CONN 1/4-20 HX




19917-4701-35  
SCR 1/4-20 30 UHD


## BACK PANEL ASSEMBLY HARDWARE



19917-4488-36  
CAM STUD



19928-0061-35  
CAM FASTENER





19896-0006-04  
3/8X1-1/2 DOWEL

## WORKSURFACE ASSEMBLY HARDWARE




19917-4327-36  
SCR TP-AB 10X1-1/2 FT PH





NOTE: WITH THE BACK PANEL ASSEMBLED ON ONE END.  
ENSURE THAT AS THE PEDESTALS ARE BROUGHT TOGETHER AND ALIGNED  
THAT THE CONNECTIONS FOR THE BACK PANEL ALIGN WITH THE OPPOSITE END PANEL.

1 ALIGN THE WORKSURFACE TO THE PEDESTALS



2 AFTER ALIGNING THE WORKSURFACE TO THE PEDESTALS, ATTACH THE WORKSURFACE

